




AP-250A Air Purifier

User Manual



Before operation, please read this manual thoroughly and retain for future reference.




IMPORTANT SAFEGUARDS:

Please read the entire instruction manual before using the product and then save it for future reference.

1. Recommend to use individual electric supply socket and not to use an extension socket, in order to avoid the danger of overheating in the outlet. Using inappropriate voltage and power outlet will damage and harm others.
2. Do not immerse the appliance or the electrical cord or plug in liquids.
3. Place the product on a flat, firm and safety place. Do not put it on the table edge or on tilted area, in order to avoid dropping or damaging the product accidentally.
4. Do not operate the product without filters or with damaged filters.
5. Not to place it where the product is exposed to condensation, due to big temperature changes. Operate it under room temperature between 0⁰-35⁰.
6. Always switch off the product before attempting to open the cover and take the filter.
7. Do not block the air inlet and outlet to avoid damage due to overheating. Place away from soft objects such as curtains. Please make sure there's 30cm distance between the object and the product which including top side, front and back side as well.
8. To avoid shortening life span or damaging your product, do not use the machine with parts or accessories that are not original. Otherwise, warranty of the product will be invalid.
9. Never operate the product without supervision. Children should be supervised by a responsible adult to ensure that they do not play with the product.
10. Do not put your fingers or other objects into the air outlet, to avoid injury and damage the product.
11. Periodically check the electric cable of the product. If the electric cable is damaged, it must be replaced by after-sales service in order to avoid danger.
12. Do not operate the product in area where gasoline, painting or flammable liquids are around. Keep the product away from heat or hot units, as it may cause explosion.
13. This product is not intended to use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
14. Before cleaning, repairing or moving the product, you must unplug it. Do not use volatile liquids or hard cloth to clean the product, as to prevent the product from scratching.
15. Do not use this appliance when you have used indoor smoke-type insect repellents or in places with oily residues, burning incense or chemical fumes.
16. Always unplug the appliance after use. When unplugging the power cord, hold the plug top, not the power cord.

Parts Description:



A、 control panel; B、 air outlet; C、 air inlet; D、 filter; E、 cover




Installation of Filters:

Please be reminded to take away the plastic bag before putting the filters in the air purifier.

Notice: Please place the product firmly before removing or installing the filter.

Remark: Be sure to install the filter in place.


1. Hold the handle of the bottom cover with one hand, turn it anticlockwise to the arrow, and pull the handle outward to remove the bottom cover (Fig 1)



(Fig 1)

2. Take out the filter screen and remove the filter bag (Fig 2, Fig 3)

Remark: Before use, be sure to remove the plastic bags of the high-efficiency filter screen, otherwise there is a risk of damage to the machine.




(Fig 2)




(Fig 3)



- Put the high efficiency filter back into the product and put it in place. (Fig 4)




(Fig 4)



(Fig 5)

- Install the bottom cover; when installing the bottom cover, first, the arrow of the bottom cover corresponds to the arrow of the whole machine, press the bottom cover inward, and then rotate clockwise; (Fig 5)
- Untie the power cord strap and connect to the power supply.

**Use instruction-:**

Button picture	Function	Instruction			
	On/Off	1) In standby mode, press power on once, and the default wind speed mode is automatic mode: speed indicator: “L→L,M→L,M,H→L...” Cycle light。 Air quality light on。 2) Press the key again to shut down the machine. Except for the key led on, other indicator lights will go out.			
	Speed control	1) After power on, press the speed button to cycle as follows, Suppose the current job is in the "L", So: “L→M→H→Auto→L”Circle; Meanwhile, the air light changes according to PM2.5			
		Air quality display	Green	Blue	Red
		speed indicator	Auto	Auto	Auto
		Motor running	L	M	H
		PM2.5	0-15	16-50	>51
2) Regardless of the gear where the speed is, it will display RGB color according to PM2.5					
	Timer	In the case of power on, press the timer key, and the timer key indicator will light up, Each time the timer is pressed, the timer will be cancel by 2h-4h-8h-off-2h----,			



		After canceling the timer, the indicator light of the timer key goes out。
	Child Rock	1) 1) When the machine is turned on, press and hold the key for 3 seconds to turn on the child lock function, and the indicator light of the child lock key is on; at this time, the other keys of the whole operation panel can't act;1) In the child lock mode, if other buttons are operated, the machine will not move, and the "child lock" indicator will flash twice (1 flash in 0.5 seconds) to remind the user that the machine is locked. 2) Press and hold the key for 3 seconds, the indicator light will go out, turn off the "child lock" function, and other keys can be activated again;
	Sleep	1) In the case of power on, press the key once to start the sleep mode: A、 Except for the sleep button, all the lights are off. B、 Motor working in sleep speed; C、 f there is a timer start, the timer will remain working normally, but it will not be displayed; D、 Except for the three buttons "on / off", "sleep", "child lock", other buttons can not be activated in sleep mode; 2) Press the key again, the sleep indicator will go out and sleep mode will be turned off。 When the wind speed is running at low speed, other indicator lights will resume, and the button will resume。 3) In sleep mode, press the "on / off" key to turn off the machine; 4) In sleep mode, press the "sleep" key to cancel the sleep mode and the machine will return to normal operation; 5) In sleep mode, you can choose to open or close the "child lock" freely, and the indicator light of the child lock is on or off, which does not affect the sleep mode.
	Light	1) Change the working conditions of indicator light and atmosphere light when the machine is turned on. Suppose that the indicator light and atmosphere light are normally on, press the button once, "Indicator light on, atmosphere light on → indicator light on, atmosphere off → indicator light off, atmosphere light off → indicator light on, atmosphere light on..."circle
	Filter replace	1) Set the cumulative working time of the machine T: $T \geq 2160$ hour, The frequency of filter screen indicator light is 1 Hz, or the icon will be off. 2) When the indicator light of filter reset button flashes, press and hold reset filter Press the button for 3 seconds, the buzzer will beep twice, and the filter screen reminder icon will go out




CAUTION:

Always be sure the purifier is switched OFF and unplugged before cleaning or attempting to store the item.

DO NOT immerse purifier in water or allow water to drip into the interior of the purifier, as this could create an electric shock hazard.

Cleaning & Care:

- Please unplug the product before clean or move it.
 - Do not immerse the cord and the whole in water or liquid.
 - Do not use detergent, metal cleaning brush, petrol, alcohol, or flammable liquids to clean the products.
 - Please do regular cleaning or replacement of filters to ensure filtration efficiency.
 - Please turn off the machine and unplug it. Leave the product for 15 minutes before cleaning starts.
 - When the product is not in use, put it back in the gift box and store it in a safe, cool and dry place that avoid direct sunlight.
1. Use soft cloth to clean the surface of the product. If it is utmost dirty, please use wet cloth which is completely wet through in warm water of temperature around 35⁰-40⁰. Please make sure the product is dried out by a dry cloth thoroughly.
 2. The 3-in-1 filter is non-washable. Recommend to use soft brush to clear the dust on the surface or put under sunshine from time to time, which helps to extend the life time of the filter. The replacement period in fact differs depending on the operation hours and environment.
 3. For dust Sensor, please use soft brush to clear the dust on its surface to restore its sensitivity. Suggest to clean it on a monthly basis.





Troubleshooting:

This section summarizes the most common problems you could encounter with the appliance. If you are unable to solve the problem, contact the Consumer Care Center in your country.

Problem	Possible Cause	Solution
Air flow from air outlet is at low level.	1. The plastic bag of the filter is not removed. 2. There are objects blocking the air outlet.	1. Take away the plastic bag. Please refer to “Installation of filters” section. 2. Clear the objects from air outlet Please refer to “Cleaning and Maintenance” section.
Air purifying performance is not obvious and no improvement in air quality.	1. Filters are not installed yet. 2. Doors or windows are always kept opened. Pollutants outside flowed into the room continuously. Therefore, it takes longer time to purify the air. 3. Product is placed in a too tight area or with objects blocking nearby. 4. Filters are dirty resulting in filtration efficiency.	1. Install the filters. 2. Do not place the product too near the window unless the window is closed. Please keep the door closed. 3. Place the product in an area with good airflow environment. 3. Clean or replace filter. Please refer to “Cleaning and Maintenance” section.
Air quality indicator light keeps at red color for very long time.	1. Dust sensor is dirty. 2. Doors or windows are always kept opened. Pollutants outside flowed into the room continuously. Therefore, it takes longer time to purify the air.	1. Please clean the dust sensor to restore its sensitivity. Please refer to “Cleaning and Maintenance” section. 2. Close the windows and door first. Turn to high fan speed so that the product can purify the air in short time.



Specification:

Item no	AP-250A
Rated voltage	120V / 60Hz
Power	45W
Recommend coverage	14-24 m ²
Noise level	<51dB
Product size	220X220X360mm



CONTACT US:

Thank you for choosing AIR CHOICE product.

If there is a defect arises during one year, please feel free to contact us to get your valid claim. To obtain warranty service, please your model and order of the product via:

✉ Support@airchoiceproducts.com

☎ +1 (855) 620 5858

Our usual response time is within 12 hours!

Scan to get vip service.



<https://airchoiceafterservice.vip>

Questions or Problems?

Tell us
We are here
to help with
our lifetime professional
100% satisfied service
within 12 hrs.



Support@airchoiceproducts.com