
Assembly Instructions

Caution: You must read this before you proceed.

Basket Chair



Parts List


Label	Picture	Description	QTY	
А		Basket Seat	1	
В		Basket Top	1	
С		Front Leg (C1)	2	
D		Back Leg (C2)	2	
E		Pillow	1	
F		Cushion	1	

Hardware

Label	Picture	Description	QTY
G		Allen Key	1
Н	∞•• 0	Bolt with Washer (M6x16MM)	13
I	 0□	Bolt with Washer (M6x30MM)	5

Assembly Preparation

Before Beginning Assembly:





Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-

Assembly Steps

Step 1




Open the carton and place all the parts onto a clean, non-marring surface. Place Basket Seat(A) on the ground, as shown in picture above.



Attach two Front Legs(C1) to the Basket Seat(A) using Bolts with Washers(H) with Allen Key(G) as shown in the picture above.


Loosely tighten the Bolts.



Turn the Basket Seat(A) around as shown in picture.

Attach Back Legs(C2) to Basket Seat(A) using Bolts with Washers(H) with Allen Key(G) as shown in picture above.

Loosely tighten the Bolts.




Stand the Basket Seat(A) upright.

Attach the Basket Top(B) to the Basket Seat(A) using Bolts with Washers(I) with Allen Key(G) as shown in picture above.

Loosely tighten the Bolts.

Caution:Two or three adults partners are required for assembly at this step.

Step 5




Check for stability and then tighten all Bolts at all joints.

Note: DO NOT fully tighten a Bolt in one go and then move on to the next.

Rather; in a sequential manner, gradually tighten each Bolt until all Bolts are evenly secured.

This methodology will ensure maximum evenness once all Bolts are fully tightened.

Step 6



Place the Cushion(F) and Pillow(E) on the Basket. Your Basket Chair is ready for use.

Care & Maintenance



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



Do not write on furniture without a padded barrier to protect the surface.



To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



Not for commercial use. For residential use only.



Stains may be removed with mild soap solution and damp cloth.





Keep away from sources of ignition.



Dust and pick-up spills using a clean, non-colored, lint-free cloth.