



## STAIR TREAD INSTALLATION

## **Staple or Tack:**

- On all four corners
- Approx. every 3 inches around tread

Tack or staple ½ inch in from the serging. Stapling or tacking on serging will cause serging to split and unravel.

