






Care and Maintenance

Dust with a soft, dry cloth. Do not use abrasive cleaner. To clean mirror, spray a small amount of glass cleaner onto a lint-free cloth and wipe mirror clean.

Notice


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

Piece	Description	Picture	Quantity
A	Leg		3 X
B	Bottom Plate		1 X
C	Glass Top		1 X
D	Assembly Finial		1 X
E	Top Plate		1 X



Model # FOX2524A
Product Dimensions: 18"W X 18"D X 26.5"H




Preparation


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.


Tools Required for Assembly (included): Assembly Finial



Step 1
Screw the Three Legs (A) into the Bottom Plate (B) as shown in the picture.



Step 2
Carefully place the Glass Top (C) on top/center of Bottom Plate (B).



Step 3
Carefully place the Top Plate (E) on top/center of Glass Top (C) and tighten them together using the Assembly Finial (D) as shown in the picture.