
Nature's Generator Powerhouse

User Manual



Nature's Generator Powerhouse

Contents

- Warning	1 1 2
Introduction	arator Powerhouse
 How to Assemble Your Nate How to Recharge Your Nate How to Use Your Nature's C How to Expand the Capacit 	aouse 8 are's Generator Powerhouse 8 Generator Powerhouse 9 Generator Powerhouse 11 y of Your Nature's Generator Powerhouse 11 Your Nature's Generator Powerhouse 12
Troubleshooting	

Technical Specifications	14
Limited Warranty	15

Important Safety Instructions

- 1. Read these instructions.
- 2. Keep this user manual in a safe and accessible place.
- 3. Take note of all warnings.
- 4. Follow all instructions.
- 5. Do not use this apparatus near water.
- 6. Do not block any ventilation openings.
- 7. Do not use near flammable gases or fumes or other apparatus that produce a large amount of heat.
- 8. Only use attachments/accessories approved by the manufacturer.
- 9. Only use with the wheels and handles approved by manufacturer, or sold with product. Use cautiously when moving with the wheels and handles to avoid tip-over injury.
- 10. Refer all servicing to qualified service personnel. Servicing is required when the equipment has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the equipment, the equipment has been exposed to rain or moisture, has been dropped or does not operate normally.
- 11. The equipment should not be exposed to dripping or splashing, and no objects filled with liquids, such as drinking glasses or vases, should be placed on the equipment.

Warning

Electric Shock Hazard

Keep away from children. Nature's Generator Powerhouse generates the same potentially lethal AC power as a normal household wall outlet. To reduce the risk of fire or electric shock, do not remove any cover or expose the device to rain or moisture. Do not insert foreign objects into the AC outlets or the ventilation holes.

Explosion Hazard

Do not burn or incinerate this item. This item may explode, causing property damage or personal injury. Do not use near flammable gases or fumes or other apparatus that produces large amounts of heat.

Lightning Hazard

For added protection for your device during a lightning storm, unplug it from the power outlet and disconnect the cables. This helps to prevent property damage and personal injury from lightning and power line surges.

Energy and Burn Hazard

Nature's Generator Powerhouse has sealed lead acid batteries, which can present a risk of burn or fire hazard from high current because of short-circuit.

Replacement Parts

When replacement parts are required, make sure that the service technician uses replacement parts specified by the manufacturer that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, personal injury, or other hazards.

Caution

Damage Requiring Service

Stop using the Nature's Generator Powerhouse and refer servicing to qualified service personnel under the following conditions:

- If liquid has been spilled or objects have fallen into your Nature's Generator Powerhouse.
- If your Nature's Generator Powerhouse has been exposed to rain or water.
- If your Nature's Generator Powerhouse has been dropped or damaged in any way.
- When your Nature's Generator Powerhouse exhibits a distinct change in performance.

Cold Weather

Cold temperatures can impact Nature's Generator Powerhouse performance. If you are in area that will be consistently below freezing, we recommend keeping your Nature's Generator Powerhouse in an insulated location and connected to solar panels.

Recycling and Disposal

Your Nature's Generator Powerhouse may contain materials that are regulated for environmental reasons.

Your Nature's Generator Powerhouse also contains materials that can be recycled and reused. To help protect the environment, contact your local authorities for information about disposal or recycling and about finding a recycler in your area before you dispose of your Nature's Generator Powerhouse.

Safety Check

After completing any service or repair to this device, ask the service technician to perform routine safety checks to determine that your Nature's Generator Powerhouse is in correct operating condition.

Servicing


These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

Introduction

Congratulations on your new Nature's Generator Powerhouse, a state-of-art generator that provides reliable power for emergencies, off grid living, or wherever power is needed.

Unpacking Your Nature's Generator Powerhouse


1. Nature's Generator Powerhouse Generator



2. Nature's Generator Powerhouse Battery Storage



3. AC Power Cord




4. This User Guide




Get to Know Your Nature's Generator Powerhouse


Front Panel



Back Panel



How to Read the LCD Display




Protection Code

- E02: The Nature's Generator Powerhouse has been protected from high temperature.
- E03: The Nature's Generator Powerhouse has been protected from high voltage of batteries.
- E04: The Nature's Generator Powerhouse has been protected from low voltage of batteries.
- E05: The Nature's Generator Powerhouse has been protected because of the short circuit of the inverter.
- E06: The Nature's Generator Powerhouse has been protected because the output voltage from the inverter is too high.
- E07: The Nature's Generator Powerhouse has been protected from over-loaded.
- E11: The Nature's Generator Powerhouse has been protected because the input from solar panels is too high
- E12: The Nature's Generator Powerhouse has been protected because the input from the wind turbines is too high
- E97: The Nature's Generator Powerhouse has been protected because the output voltage from the inverter is too low.
- E98: Communication fails
- E99: The inverter fails to start up.

Using Your Nature's Generator Powerhouse

How to Assemble Your Nature's Generator Powerhouse


- 1. Gently move your Nature's Generator Powerhouse Battery Storage to the desired location. Please be aware that two wheels have breaks. Release the breaks before you start moving Nature's Generator Powerhouse Battery Storage.
- Team lift Nature's Generator Powerhouse Generator and place it on top of the Nature's Generator Powerhouse Battery Storage. Make sure they are aligned Properly. If the ground is uneven or sloping, please add the shim(s) under the wheels to keep your Nature's Generator Powerhouse leveled.
- 3. Lock the latches on both sides.
- 4. Connect the expansion cable from Nature's Generator Powerhouse Battery Storage to the Battery = Generator Port on the back of Nature's Generator Powerhouse Generator.




How to Recharge Your Nature's Generator Powerhouse

Recharging from Nature's Generator Powerhouse Power Panels (sold separately):


- 1. Place your Nature's Generator Powerhouse Power Panels where they will get as much direct sunlight as possible. While direct sunlight is always preferred, the power panels will also send a small amount of charge to your Powerhouse during hazy or overcast sky conditions.
- 2. Connect two Nature's Generator Powerhouse Power Panels in series.



3. Connect the MC4 connectors of your Power Panel Cable to the remaining MC4 connectors on the Nature's Generator Powerhouse Power Panels. Minimum two serial connected Nature's Generator Powerhouse Power Panels are needed to recharge Nature's Generator Powerhouse.



- 4. Insert Power Panel Cable plug into Solar Input port on the front of your Nature's Generator Powerhouse. You will know it is recharging when LCD display lights up, solar panel icon is illuminated, and battery bar starts running. The battery bar will stop running when the battery is full or there is not enough power from Nature's Generator Powerhouse Power Panels.
- 5. It usually takes about 8 to 15 hours to recharge the Nature's Generator Powerhouse if using two Nature's Generator Powerhouse Power Panels. The recharging time, of course, also depends on the temperature and the strength of the sunlight.
- 6. To increase the recharging speed, you can connect the two serial connected Nature's Generator Powerhouse Power Panels in parallel connection. The Solar Input port can handle up to 2000 watts of solar power. Visit Naturesgenerator.com for more information about Nature's Generator Powerhouse Power Panels



Recharging from the Nature's Generator Powerhouse Wind Turbine (sold separately):

- 1. Place your Nature's Generator Powerhouse Wind Turbine where it will get sufficient wind.
- 2. Follow the manual of Nature's Generator Powerhouse Wind Turbine to set up the wind turbine.
- 3. Insert the wind turbine cable connector into Wind Input port on the front of your Nature's Generator Powerhouse. You will know it is recharging when LCD display lights up, wind turbine icon is illuminated, and battery bar starts running. The battery bar will stop running when the battery is full or there is not enough power from wind turbine. The recharging speed depends on the strength of the wind.
- 4. To increase the recharging speed, connect another Nature's Generator Powerhouse Wind Turbine by the dual charger controller. The Wind Input port can handle up to 1000 watts of wind power. Visit Naturesgenerator.com for more information about Nature's Generator Powerhouse Wind Turbine.

Recharging from AC Power

- 1. Insert the power cord to the AC Input Port on the back of the Nature's Generator Powerhouse.
- 2. Plug the other end of the power cord into the wall outlet. You will know it is recharging when LCD on the front of Nature's Generator Powerhouse display lights up, AC input icon is illuminated on the LCD display and battery bar starts running. The battery bar stops running when the battery is full and the AC Input light changes from red to green. Nature's Generator Powerhouse AC Output will shutdown automatically when it is be recharging from AC power.

How to Use Your Nature's Generator Powerhouse

- 1. Press the Main Power Switch to turn on your Nature's Generator Powerhouse. DC and USB ports will be on automatically when the Main Power Switch is on.
- 2. Press the AC Output Switch to turn on the AC outlets. When not using the AC outlets, make sure to turn off AC Output Switch to conserve power.
- 3. Plug in your devices for power.

How to Expand the Capacity of Your Nature's Generator Powerhouse

You can extend the run time of your Nature's Generator Powerhouse by connecting it to the Nature's Generator Powerhouse Power Pod (sold separately). Visit naturesgenerator.com to purchase Nature's Generator Powerhouse Power Pod.

- 1. Locate the expansion cable on Nature's Generator Powerhouse Power Pod and run the expansion cable to the back of the Nature's Generator Powerhouse.
- 2. Locate Expansion In Port on the back of your Nature's Generator Powerhouse and open the cover.
- 3. Connect the expansion cable to the Expansion In port.
- 4. The Expansion (Chain Link) Icon will be illuminated on the LCD display to indicate it is connected. You will experience an increased run time of 100% by adding one Nature's Generator Powerhouse Power Pod, 200% by adding two Nature's Generator Powerhouse Power Pods and 300% by adding three Nature's Generator Powerhouse Power Pods.

How to Maintain and Store Your Nature's Generator Powerhouse

Turn off the main switch and AC switch when your Nature's Generator Powerhouse is not in use. Recharge your Nature's Generator Powerhouse once every four months and store it in a ventilated, cool and dry location. This keeps the battery healthy and prolongs its life. Failure to maintain Nature's Generator Powerhouse by these steps can result in battery damage which will void the product warranty.

Clean your Nature's Generator Powerhouse with a soft, lint-free cloth. If your Nature's Generator Powerhouse is very dirty, moisten a soft, lint-free cloth in a weak detergent solution, squeeze the excess moisture from the cloth, then wipe Nature's Generator Powerhouse with the cloth, followed by a clean dry cloth to wipe down you Nature's Generator Powerhouse.

Troubleshooting

My Nature's Generator Powerhouse won't charge when I connect my solar panel to it.

Please follow these steps.

- 1. Make sure the solar panels are pointed directly towards the sun. The most efficient power generating position is with solar panels facing south. . The solar panels may produce little or no power if they are positioned in the shade.
- 2. Check the cable connection on your Nature's Generator Powerhouse and make sure it is properly connected.
- 3. If the LCD lights up but the battery bar is not running, it means the solar panels do not have high enough voltage to recharge the Nature's Generator Powerhouse or the Nature's Generator Powerhouse has been fully recharged by the solar panels.

My Nature's Generator Powerhouse Power Pod won't charge when I connect my wind turbine to it.

Please follow these steps.

- 1. If you are not using Nature's Generator Powerhouse Wind Turbine, make sure the wind turbine has similar characteristics.
- 2. Make sure there is sufficient wind that spins the wind turbine fast enough. The wind turbine must spin fast enough to generate higher voltage than Nature's Generator Powerhouse Power Pod before the wind turbine can charge Nature's Generator Powerhouse Power Pod.
- 3. Check the cable connection on your Nature's Generator Powerhouse Power Pod and make sure it is properly connected.
- 4. If battery level LEDs light up, but are not running, it means the wind turbine does not have high enough voltage to recharge the Nature's Generator Powerhouse Power Pod.

My AC device(s) are not powering up from my Nature's Generator Powerhouse.

Please follow these steps:

- Verify your device is suitable for use with your Nature's Generator Powerhouse. The Nature's Generator Powerhouse Line 1 and 2 outlet works only with 240V AC 30A maximum. (7200 watts). Line 1 or Line 2 outlets work only with 120V AC 30A maximum (3600 watts). Some devices might require grounding before they can be used. Ground Nature's Generator Powerhouse before power this type of devices.
- 2. Make sure the Main Power Switch is turned on.
- 3. Check the battery bar. If there are four bars or less, recharge your Nature's Generator Powerhouse. Some AC device draws large amounts of power when starting up. It is recommended to recharge your Nature's Generator Powerhouse full before heavy use.
- 4. Make sure the AC Output Switch is turned on. The AC outlet light should be green.
- 5. If LED light is red, please check FUSE icon, Protection icon and protection code(s) on the LCD display.

My Nature's Generator Powerhouse battery drains fast.

Please follow these steps.

- 1. Check the wattage of your AC device(s). Some devices like a hair dryer, microwave or vacuum draw large amounts of power and thus the battery drains fast. Please always monitor the wattage output information on the LCD display.
- 2. When your AC device is not in use, turn off AC outlets of your Nature's Generator Powerhouse to conserve power. The AC outlets consume a considerable amount of power while being in standby mode.
- 3. When Nature's Generator is not in use, turn off the Main Power Switch to eliminate unnecessary battery drainage by turning off the LCD display and USB ports.

Technical Specifications

Battery:

Type: AGM Sealed Lead Acid Capacity: 48V 100Ah (4800Wh) Self-discharge: Recommend to recharge every 4 months

Inverter:

Output Power: 7200 watt max Output voltage: 120V/240V Split Phase Output frequency: 60Hz Output Sine Wave: Pure sine wave Output Phase: Split phase

Ports:

USB Output: QC 3.0 Type-C Output: PD3.0 12V Socket: 10A max 12V Port: 10A max 48V Port: 5A max Expansion Port: 175A max

Charges:

AC Charger: 1300W AC Charger Indicator: red (charging) and green (charged) Solar Charger: 2000watt Wind Charger: 1000watt

General:

Dimensions: Power house : 28 x 18 x 19 inches (720*466*473mm) Power house (with wheels): 28 x 18 x 22 inches (720*466*568mm) Operating temperature: 32-104 °F (0-40 °C) Storage Temperature: 23–111 °F (-5–45 °C) Weight: 434 lbs (197 kg)

Limited Warranty

One Year Limited Warranty

Natures Generator Inc. warrants to you, the original purchaser of this new product, that the product shall be free of defects in the original manufacture of the material or workmanship for a period of one (1) year from the original date of your purchase of the product ("Warranty Period"). This product must be purchased from an authorized dealer and packaged with this warranty statement. This warranty does not cover refurbished product.

What does this Warranty Cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the product is determined to be defective by an authorized dealer, Natures Generator Inc. will (at its sole option): (1) repair the product with new or rebuilt parts; or (2) replace the product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Nature's Generator and are not returned to you. If service of products or parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the product.

How to Obtain Warranty Service?

Please call 1-800-975-7909 Monday through Friday, 9:00AM to 5:00PM PST. You will be provided with a Return Merchandise Authorization (RMA) number and return instructions. Send product to:

Natures Generator Inc. 3130 Paseo Mercado Suite 106 Oxnard, CA 93036

Please include the RMA number prominently displayed on the shipping box and include your name, phone number and address with the product inside the box.

Where is the Warranty Valid?

This warranty is valid only to the original purchaser of the product in North America (United States, Canada).

What does the Warranty not Cover?

This warranty does not cover:


- Cosmetic damage
- Damage due to force majeure, such as lightning strikes, fire, flood, etc..
- Accident
- Misuse
- Abuse
- Negligence
- Commercial use
- Modification of any part of the product
- Damage due to incorrect operation or maintenance
- Connection to an incorrect voltage supply
- Attempted repair by anyone other than a facility authorized by Natures Generator Inc. to service the product
- Products sold as is or with all faults
- Consumables, such as batteries
- Products where the factory applied serial number has been altered or removed

REPAIR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY. NATURES GENERATOR INC. SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. NATURES GENERATOR INC. PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

Contact Natures Generator Inc: For customer service please call 1-800-975-7909 Natures Generator Inc. 3130 Paseo Mercado Suite 106 Oxnard, CA 93036



V1.0 ENGLISH 22-0627




Do not damage or scratch the surfaces of the Nature's Generator Powerhouse Power Panels.

visit NaturesGenerator.com for more information

Nature's Generator Powerhouse Wind Turbine

User Manual



Nature's Generator Powerhouse Wind Turbine Contents

Welcome

Congratulations on the purchase of your new Nature's Generator Powerhouse Wind Turbine, a state-of-art wind turbine that recharges your Nature's Generator Powerhouse or Nature's Generator Powerhouse Power Pod with wind power. Please read these instructions thoroughly prior to installation, then store this manual in a safe place for future reference. If at any time you have questions about this product, or require additional assistance, please do not hesitate to email us at support@naturesgenerator.com or contact our Customer Support line at 800-975-7909.

Important Safety Instructions

- 1. Read these instructions.
- 2. Keep these instructions.
- 3. Take note of all warnings.
- 4. Follow all instructions.
- 5. Place this manual in a safe place for future reference.
- 6. Only use attachments/accessories specified by the manufacturer.
- 7. Refer all servicing to qualified service personnel. Servicing is required when the Nature's Generator Powerhouse Wind Turbine has been damaged in any way, such as cord or plug is damaged, or the Nature's Generator Powerhouse Wind Turbine has been dropped.
- 8. Wait until a calm day to install the Nature's Generator Powerhouse Wind Turbine.
- 9. Avoid the sharp edges on the blades.
- 10. Readjust and tighten the screws and bolts as needed after installation.
- 11. Your Nature's Generator Powerhouse Wind Turbine must be installed in accordance with this manual along with local and national building code. Incorrect installation may void warranty.
- 12. Your Nature's Generator Powerhouse Wind Turbine blades spin at a potentially dangerous speed. <u>Never approach turbine in motion.</u>

Warning

Mechanical Hazard

The rotating blades present a serious mechanical hazard. The top of the rotating blades may be moving at the speed over 300 miles per hour. The blades are almost invisible when spinning and may cause serious injuries. You should NOT install the turbine where anyone could come in touch with the rotating blades.

Electrical Hazard

The Nature's Generator Powerhouse Wind Turbine generates electricity and thus an inherent personal injury from electricity exists. Be always cautious when connecting cables and when connecting to Nature's Generator Powerhouse or Nature's Generator Powerhouse Power Pod.

Replacement parts

When replacement parts are required, make sure that the service technician uses replacement parts specified by the manufacturer that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, personal injury, or other hazards.

Safety check

After completing any service or repair to this device, ask the service technician to perform routine safety checks to determine that your Nature's Generator Powerhouse Wind Turbine is in optimal operating condition.

Servicing

These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

Caution

Damage requiring service

Stop using the Nature's Generator Powerhouse Wind Turbine and refer servicing to qualified service personnel under the following conditions:


- If your Nature's Generator Powerhouse Wind Turbine has been dropped or damaged in any way.
- When your Nature's Generator Powerhouse Wind Turbine exhibits a distinct change in performance.

End of life directives

Your Nature's Generator Powerhouse Wind Turbine may contain materials that are regulated for environmental reasons. Your Nature's Generator Powerhouse Wind Turbine also contains materials that can be recycled and reused. In the future, to help protect the environment, contact your local authorities for information about disposal or recycling of your Nature's Generator Powerhouse Wind Turbine or any replaced components.

Unpack Your Nature's Generator Powerhouse Wind Turbine

1. Nature's Generator Powerhouse Wind Turbine main body




2. Hub



3. Nose cone




4. Blades x 3



5. 100-foot-long wind turbine cable



6. Controller box




7. This user manual



8. Accessory bag that includes.

0	M8 bolt x 7 (1 spare pieces)				
	M8 nut x 7 (1 spare pieces)				
Q	M8 lock washer x 7 (1 spare pieces)				
	M20 lock nut x 1				
Q	M20 lock washer x 1				
	Rubber pad x 1				
	Hex key 8mm				
	Hex key 6mm				
\bigcirc	Gasket				
	Ground line				

Get to Know Your Nature's Generator Powerhouse Wind Turbine



Complete Electrical System


Your Nature's Generator Powerhouse Wind Turbine comes with 100 foot long wind turbine cable and controller box. It is a complete electrical system to recharge your Nature's Generator Powerhouse or Nature's Generator Powerhouse Power Pod.

Built-in Protections

Your Nature's Generator Powerhouse Wind Turbine controller box has built-in over-current protection and over voltage protection that prevent possible damage to your Nature's Generator Powerhouse Power Pod.


Grounding

Every wind turbine and turbine tower need to be grounded at the tower base. Grounding the tower at its base may help prevent shocks to persons touching the tower due to lightning or electrical faults. Please take the time to review the National Electrical Code (NEC) and local building and zoning regulations for complete requirements. Your Nature's Generator Powerhouse Wind Turbine has a grounding cable included for this purpose.



Expandability

Your Nature's Generator Powerhouse Wind Turbine can be connected to another Nature's Generator Powerhouse Wind Turbine to double the charging speed by using Nature's Generator Powerhouse Wind Turbine Dual Controller Box. Please visit www.naturesgenerator.com or contact Customer Support line at 800-975-7909 or email us at support@naturesgenerator.com for more information.




Using Your Nature's Generator Powerhouse Wind Turbine

How to choose the location

The wind speed has dramatic effects on your Nature's Generator Powerhouse Wind Turbine. The location should be carefully considered to achieve the optimal performance of your Nature's Generator Powerhouse Wind Turbine, prior to the mounting of your Nature's Generator Powerhouse Wind Turbine. Each installation is unique and often requires some compromise among surrounding environment, distance between your Nature's Generator Powerhouse Wind Turbine and your Nature's Generator Powerhouse or Nature's Generator Powerhouse Power Pod, zoning requirements, budget and etc.

In general terms, the higher your Nature's Generator Powerhouse Wind Turbine can be mounted, the greater the air flow will be and thus the better power production will be. However, towers are expensive and can easily exceed the cost of the turbine. The minimum recommended tower height is 20ft to 30ft above nearby obstructions as shown below. The obstructions create turbulence which reduces the efficiency of the wind turbine may accelerate wear and tear of your Nature's Generator Powerhouse Wind Turbine.

Safety must be the primary concern when selecting the mounting location. Install your Nature's Generator Powerhouse Wind Turbine so there is no possibility of accidental contact with the rotating blades even if it requires installing the wind turbine in a less than ideal location. Safety has precedence over efficiency.



How to choose the tower

Your Nature's Generator Powerhouse Wind Turbine is designed to mount on nominal 1.5 inch schedule 40 steel tubing or piping. The outside diameter of the tubing or piping shall be around 1.875 inch to 1.900 inch. The steel tubing or piping should be available through your local hardware store. Under no circumstances should plastic pipe be used to construct a tower. Towers must be capable of withstanding 270 pounds of load in the horizontal direction at the wind turbine.


How to Install your Nature's Generator Powerhouse Wind Turbine

Caution: Choose a calm day and have someone available to help during the installation process.


Caution: The blades' edges are sharp. Please handle carefully.

Caution: Do not assemble the blades before the body is mounted on the pipe or tower. Caution: Do not connect your Nature's Generator Powerhouse Wind Turbine with Nature's Generator Powerhouse or Nature's Generator Powerhouse Power Pod. until all installation has been completed.


Step 1: Run the wind turbine cable through the pipe and drag the connector close to the Nature's Generator Powerhouse or Nature's Generator Powerhouse Power Pod. The female connector should be close to your Nature's Generator Powerhouse Wind Turbine and the male connector should be close to your Nature's Generator Powerhouse or Nature's Generator Powerhouse Power Pod.




Step 2: Connect the wind turbine cable and your Nature's Generator Powerhouse Wind Turbine by pushing and twisting the connectors.




Step 3: The rubber gasket that is stored inside of the yaw and the included rubber pad will help to prevent the the yaw from contacting the pipe directly. The rubber gasket and rubber pad will assist in reducing the transmission of noise and vibration down the pipe. Slide the yaw shaft all the way down over the top of the pipe and be careful not to pinch the cable. There may be some slight variances of the thickness or size of the pipe from different makers or models. Please adjust the size of rubber pad as needed.



Step 4: Firmly tighten the yaw clamp bolts with the 6mm hex key. Be sure that your Nature's Generator Powerhouse Wind Turbine is securely attached to the pipe.




Step 5: Place one of the blades on one of the hub sockets. Place a lock washer and then a flat washer on the bolt and then insert the bolt through the blade and the socket. Place a nut on the other side of socket and tighten the bolt with the 5mm hex key. Repeat this process on all three blades. Make sure the lock washer and flat washer are placed in the right order. The blades will become loose if they are not installed properly.






Locker washer and flat washer must be placed in the right order to secure the blades in place.


Step 6: Slide the blade assembly onto the rotor shaft and place the lock washer and lock nut on the shaft. Make sure the lock washer is right next to the lock nut.



Step 7: Insert the 8mm hex key into the rotor shaft. Hold the blade assembly and tighten the M16 nut by turning the 8mm hex key counter clockwise. It is recommended to use a hex key extender (not included) that provides more leverage to tighten the lock nut. Finally, spin the blades slowly to be sure they turn freely and the hub does not move in along the rotor shaft.



Step 8: Place the nose cone over the center of the blade assembly and snap the nose cone into place.




Step 9: Carefully raise the tower and secure the base and/or cables.


Visit NaturesGenerator.com for More Information

How to Use Your Nature's Generator Powerhouse Wind Turbine

Step 1: Connect the wind turbine cable to the round connector from one side of the controller box by pushing and twisting the connectors.




Step 2: Connector the square connector from the other side of controller box to your Nature's Generator Powerhouse's or Nature's Generator Powerhouse Power Pod's "WIND INPUT" port.



Step 3:

For use with Nature's Generator Powerhouse.

When your Nature's Generator Powerhouse Wind Turbine spins at a certain speed, you will see that the whole display on your Nature's Generator Powerhouse lights up if your Nature's Generator Powerhouse main power is switched off. This means your Nature's Generator Powerhouse Wind Turbine is recognized by your Nature's Generator Powerhouse, but it is not yet powerful enough to recharge your Nature's Generator Powerhouse. When your Nature's Generator Powerhouse Wind Turbine spins at proper higher speed, you will see that wind turbine icon on the display illuminates and battery bar starts running. This means your Nature's Generator Powerhouse Wind Turbine is recharging your Nature's Generator Powerhouse.



For use with Nature's Generator Powerhouse Power Pod.

When your Nature's Generator Powerhouse Wind Turbine spins at certain speed, you will see that the battery level LEDs on your Nature's Generator Powerhouse Power Pod light up if your Nature's Generator Powerhouse Power Pod is switched off. This means your Nature's Generator Powerhouse Wind Turbine is recognized by your Nature's Generator Powerhouse Power Pod, but it is not powerful yet to recharge your Nature's Generator Powerhouse Power Pod. When your Nature's Generator Powerhouse Wind Turbine spins at proper higher speed, you will see the battery level LEDs start running. This means your Nature's Generator Powerhouse Wind Turbine is recharging your Nature's Generator Power Pod.

BATTERY LEVEL								
0	0	0	0	0	0	0	0	

MAINTENANCE

Your Nature's Generator Powerhouse Wind Turbine has been designed to run for long periods without requiring any maintenance. Performance will be enhanced if you periodically inspect your system. Review the following simple maintenance procedures and implement every six months.

Caution: Do not go near the wind turbine during operation.

• Check blades for superficial damage. Replace blades if damaged. It is important not to use blades that are damaged, as you will lose overall balance, resulting in a decrease in efficiency. Should you notice damage to the blades, you must replace all three blades. The blades are balanced as sets.

- Check the blade bolts and the nut for tightness.
- Check nose cone for cracks and tighten nuts.
- Wipe any excess dirt build-up from the blades.
- Check electrical connections to make sure they are tight and free from corrosion.
- Lubricate the bearings to reduce the friction.

Trouble shooting

Caution: You may require an extra person to assist with these tests.

- 1. Remove the blades and hub from your Nature's Generator Powerhouse Wind Turbine.
- 2. Drain your Nature's Generator Powerhouse to show only one bar or two bars of battery level.
- 3. Make sure your Nature's Generator Powerhouse main power is switched off. Connect your Nature's Generator Powerhouse Wind Turbine to your Nature's Generator Powerhouse.
- 4. Set your power drill at speed mode and use an 8mm hex drive bit (not inlcuded) to spin the rotor shaft.
- 5. You will see that the LCD display on your Nature's Generator Powerhouse lights up and then your wind turbine icon illuminates and the battery bar starts running. This means your Nature's Generator Powerhouse Wind Turbine is recharging your Nature's Generator Powerhouse. You should also feel resistance on the rotor shaft.

If you have any questions on the troubleshooting procedures, please do not hesitate to email us at support@naturesgenerator.com or contact our Customer Support line at 800-975-7909.

Technical Specifications

Material: Wind turbine blades: fiberglass nylon composite Wind turbine body: cast aluminum alloy with powder coating Wind turbine cable: 12AWG pure copper cable

Connectors: Wind turbine cable connectors: weatherproof M19 3P connectors. Wind input connectors: Anderson connectors. Yaw: fits 1.5 Inch schedule 40 pipes or towers

Power Rating: Rated power: 350 watts @ 27 MPH Maximum wind speed 110 mph

General: Rotor diameter: 63 in / 1.6 m Weight: 37 lbs/17 kg not including cables and controller box. Certifications: CE Rohs

Limited Warranty

One Year Limited Warranty

Natures Generator Inc. warrants to you, the original purchaser of this new product, that the product shall be free of defects in the original manufacture of the material or workmanship for a period of one (1) year from the original date of your purchase of the product ("Warranty Period"). This product must be purchased from an authorized dealer and packaged with this warranty statement. This warranty does not cover refurbished product.

What does this Warranty Cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the product is determined to be defective by an authorized dealer, Natures Generator Inc. will (at its sole option): (1) repair the product with new or rebuilt parts; or (2) replace the product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Nature's Generator and are not returned to you. If service of products or parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the product.

How to Obtain Warranty Service?

Please call 1-800-975-7909 Monday through Friday, 9:00 am to 5:00 pm PST. You will be provided with a Return Merchandise Authorization (RMA) number and return instructions. Send product to:

Natures Generator Inc. 3130 Paseo Mercado Suite 106 Oxnard, CA 93036

Please include the RMA number prominently displayed on the shipping box and include your name, phone number and address with the product inside the box.

Where is the Warranty Valid?

This warranty is valid only to the original purchaser of the product in North America (United States, Canada).

What does the Warranty not Cover?

This warranty does not cover:

- Cosmetic damage
- Damage due to force majeure, such as lightning strikes, fire, flood, etc..
- Accident
- Misuse
- Abuse
- Negligence
- Commercial use
- Modification of any part of the product
- Damage due to incorrect operation or maintenance
- Connection to an incorrect voltage supply
- Attempted repair by anyone other than a facility authorized by Natures Generator Inc. to service the product
- Products sold as is or with all faults
- Consumables, such as batteries
- Products where the factory applied serial number has been altered or removed

REPAIR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY. NATURES GENERATOR INC. SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. NATURES GENERATOR INC. PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

Contact Natures Generator Inc: Natures Generator Inc. 3130 Paseo Mercado Suite 106 Oxnard, CA 93036

For customer service please contact support@naturesgenerator.com or call 1-800-975-7909.

