

BE YOUR LIFE BUILDER www.patiowell.com



ASSEMBLY INSTRUCTIONS


RESIN GARDEN SHED

SKU: T-PS24-0436A





SITE PREPARATION

Level the ground surface.




Recommendation: Construct a wooden or concrete base as a foundation.





The external dimensions of the product:



BEFORE STARTING ASSEMBLY


Remove all of the pieces from the 2 packages and spread them out on the ground. Before installation, please check the type and quantity of parts first.

It is recommended to use a clean work surface to spread the parts out and for pre-assembly steps. Review all instructions before you begin, continue to refer to instructions during assembly.

Be sure to follow all steps thoroughly.

Please prepare these components in advance at the beginning of each stage.

REQUIRED TOOLS



CAUTION

Some parts have steel edges. Please be careful when handling components. Always wear work gloves, eye protection and long sleeves when assembling or performing any maintenance on your shed. Do not attempt assembly on days with strong winds or low temperatures.




Requires two people and takes 2-3 hours for Installation. Recommended to wear gloves to avoid scratches. Please read the manual carefully before installation.


TO THE STORE

Contact us first
saleservice@patiowell.com


FLOOR PARTS




WALL PARTS




WINDOW PARTS




ROOF PARTS




DOOR PARTS



ACCESSORIES




SCREW




CHOOSE THE LOCATION OF THE WINDOW


Multiple methods exist for installing wall panels with windows, with our instructions detailing the first method of installation.(as shown in the picture)





CONTENTS


Floor Part Instruction	09-13 (page)
Wall Part Instruction	13-22 (page)
Roof Part Instruction	23-30 (page)
Door Part Instruction	31-33 (page)






















































































Note the snaps on C7-1.





For Front Door


















































*>> SC5x14 60 pcs




















CARE & SAFETY

- In case of fire, do not attempt to extinguish any burning polypropylene with water Unsuitable for storage of flammable or corrosive substances.
- It is of utmost importance to assemble all of the parts according to the directions. Do not skip any step.
- Please consult your local authorities if any permits are required to erect shed.
- Periodically check shed to assure that it remains stable and that the site remains level.
- It is highly recommended to secure the shed to an immovable object or to the ground by drilling holes in the floor at the pre-marked locations and inserting proper screws into the ground (size: 1.9"-3", screws are not included).
- Wear safety-goggles and always follow the manufacturer's instructions when using power tools.
- Wash shed with garden hose or a mild detergent solution. Using a stiff brush or abrasive cleaner could damage shed.
- Hot items such as recently used grills, blowtorches, etc. must not be stored in the shed.
- Heavy articles should not be leaned against the walls, as this may cause distortion.
- Keep roof clean of snow and leaves. Heavy amounts of snow on roof can damage the shed making it unsafe to enter.
- Although wind direction varies, it is an important factor when taking into account where to place your shed. Therefore, it is recommended to reduce wind exposure of the shed in general, and the door side in particular.
- Keep doors closed and locked to prevent wind damage.
- Do not stand on the roof.