

TABLE OF CONTENTS

| | | | |
|--|---|--------------------------------------|----|
| Quick Start..... | 2 | Operating Instructions..... | 13 |
| Specifications..... | 4 | How to Clean..... | 14 |
| Limited Warranty..... | 4 | Operating Tips and Maintenance | 14 |
| Introduction..... | 5 | Storage..... | 16 |
| Safeguard, Warnings & Safety Tips..... | 5 | Pump Saver..... | 17 |
| GFCI..... | 6 | Replacement Parts..... | 18 |
| Package Content..... | 7 | Troubleshooting and FAQ..... | 19 |
| Unpacking & Assembly..... | 8 | | |

SPECIFICATIONS

| Model | Max PSI (lbs/sq in) | Max GPM (gal/min) | Max Temp | Volts | Amps | Weight (lbs) |
|----------|---------------------|-------------------|---------------------|-------|------|--------------|
| PWE-1800 | 1,800 | 1.3 | For cold water only | 120 | 13 | 26 |

LIMITED WARRANTY

ECHO Incorporated's Limited Warranty, provides to the original purchaser that this ECHO product (including the spray gun, high pressure hose, accessories and parts purchased separately) are free from defects in material and workmanship for a period of one year from the date of purchase. THIS LIMITED ONE YEAR WARRANTY APPLIES ONLY TO PRODUCTS USED IN CONSUMER APPLICATIONS AND IS VOID IN RENTAL OR COMMERCIAL APPLICATIONS. Under normal use and maintenance from date of purchase, ECHO agrees to repair or replace at ECHO's discretion, any defective product free of charge. THIS LIMITED WARRANTY IS EXTENDED TO THE ORIGINAL PURCHASER ONLY, AND IS NOT TRANSFERABLE TO SUBSEQUENT OWNERS. Repair parts and accessories replaced under this warranty are warranted only for the balance of the original warranty period. Reasonable care must be used in conformity with operation and maintenance instructions in the owner's manual and quick start guide. Any damage caused by failure to follow these instructions will void this warranty. All parts or products replaced under warranty become the property of ECHO, Inc.

To ensure trouble free warranty coverage it is important that you register your ECHO product on-line at WWW.ECHO-USA.COM Registering your product confirms your warranty coverage and provides a direct link if we find it necessary to contact you.

Should a product difficulty occur within the warranty period, you must, at your expense, deliver or ship your ECHO unit to an authorized ECHO servicing location (normally the place where you purchased the unit) and arrange for pick-up or return of your unit after the repairs have been made. It is the owner's responsibility to provide a dated proof of purchase (receipt) to an authorized ECHO servicing location for warranty service. Should you require assistance or have questions concerning ECHO's Warranty policy, you can contact our Consumer Product Support Department at 1-800-673-1558 or contact us through the web at WWW.ECHO-USA.COM or E-Mail us at support@echo-usa.com.

This limited warranty is in lieu of all other expressed or implied warranties, including any warranty of FITNESS FOR A PARTICULAR PURPOSE OR USE and any implied warranty of MERCHANTABILITY otherwise applicable to this product. ECHO and its affiliated companies shall not be liable for any special incidental or consequential damage, including lost profits. There are no warranties extended other than as provided herein. This limited warranty may be modified only by ECHO. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so you may also have other specific legal rights which vary from state to state. This limited warranty is given by ECHO Incorporated, 400 Oakwood Rd., Lake Zurich, IL 60047.