

- **If doorbell is humming or buzzing, remove push button and check for diode. If a diode is installed, loosen the screws and remove.**
- **If video doorbell is connected to this product and it is not functioning correctly, contact the video doorbell manufacturer.**