## Table of Contents

Table of Contents	
Safety Information	
Warranty	
3 Years Warranty	
What is Covered	
What is Not Covered	
Pre-assembly	
Planning Assembly	

Tools Required	3
Hardware Included	
Pre-assembly (continued)	
Assembly	
Maintenance	
Care and Cleaning	12

# Safety Information



## DANGER

- Keep small parts away from children during assembly.
- Read and follow instructions carefully.



# **MARNING**

- TO GUARANTEE THE SAFE USE OF THIS PRODUCT, FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL.
- Adult assembly required.
- Small parts may present choking hazard prior to assembly.

## A CAUTION

- Do not use power tools to assemble your furniture. Power tools may strip or damage parts/product.
- Do not overtighten connectors (screws, bolts, etc.). Overtightening can lead to product damage.
- Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact THE HOME DEPOT to obtain any missing parts.
- DO NOT USE SUBSTITUTE PARTS. This product should only be used on a flat, level surface. Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.
- Assembly requires two people; assembly alone may cause injury.
- Before using the product be sure that it is completely and properly assembled.

During assembly children should be kept away from the product to avoid possible risk of injury.

Regularly check screws to ensure they are tightened securely.

# Warranty

## 3 YEARS WARRANTY

## WHAT IS COVERED

We guarantee this product to be free of manufacturing defects to the original purchaser for three years.

#### WHATIS NOT COVERED

This warranty does not cover commercial use, acts of nature, and abusive use.