WARNING

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

CARE AND MAINTENANCE

Unplug lamps before using any cleaning solutions. Dust shades with a feather duster or with an appropriate vacuum-brush attachment. Wipe with a soft, dry cloth and clean lamp bases with the methods appropriate to the material. Avoid the use of chemicals and household cleaners as they may damage the finish.

NOTICE& IMPORTANT SAFETY INSTRUCTIONS

* Please make sure that you have all parts indicated before you begin assembly of this item

- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation

*The external flexible cable or cord of this lamp cannot be replaced;

If the cord is damaged, the lamp shall be destroyed


**This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. this plug will fit in a polarized outlet only one way. if the plug does not fit fully in the outlet, reverse the plug, if it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. do not attempt to disregard this safety feature.

QUANTITY PIECE DESCRIPTION PICTURE QUANTITY PIECE DESCRIPTION PICTURE -A.B.C.D Е 1X Lamp base 1X Harp В Neck 1X F Shade 1X С Saddle 1X G Finial 1X Н D Socket ð 1X Bulb 1X

Part List and Hardware List



Model# JYL6208 Product Dimensions: 15"Lx 15"W x 27"H



PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 6 minutes.

If there are any questions relating to defects, missing parts, assembly issues, replacements, or device connectivity issues, please send a detailed email to cs@jonathany.com

 $\mathbf{2}$

PLEASE USE ON/OFF TYPE"A" BULB MAX 100-WATT OR LED BULB MAX 12-WATT.THERE IS LED 9-WATT BULB IN THE BOX









Pull power cord to connect the Neck (B) to the Base (A). Screw the Neck (B) onto the Lamp base (A) Be careful not to twist the power cord and tighten securely

ENJOY YOUR LAMP

Step 2

Insert the Harp (E) into the Saddle (C). Put the shade(F) on the Harp(E),then tighten the Finial (G)into the Harp (E) Insert the bulb(H) into the socket(D).





3