

RV Sink Installation Manual

I. Pre-Installation Preparation

- . Check if the package components are complete, including the folding faucet, cutting board, cut-out template, mounting hardware, drain pipe, and strainer.
- . Ensure that the installation location is a suitable area in the RV and that the space can accommodate the sink and related components.
- . Prepare the required tools, such as screwdrivers and wrenches.

II. Installation Steps

- . According to the cut-out template, mark and cut a suitable hole at the installation location in the RV for embedding the sink.
- . Place the sink into the cut hole and adjust its position to ensure it is placed stably.
- . Use the accompanying mounting hardware to fix the sink to the installation location, ensuring it is securely installed.
- . Install the folding faucet in the reserved hole of the sink, connect the hot and cold water pipes, and ensure the connections are sealed to prevent water leakage.

- . Install the drain pipe and strainer, paying attention to sealing during connection to avoid sewage leakage.
- . Check if all components are installed in place, turn on the faucet to test the water flow and drainage, and check for water leakage.

III. Usage and Maintenance

- . In daily use, the cutting board can be placed on top of the sink as an extra workspace.
- . When cleaning the sink, take advantage of its rounded corner design and sandblasted matte surface to easily remove stains. Avoid using sharp objects to scratch the surface to prevent damage.
- . Regularly check the connections of the faucet, drain pipe and other components, and tighten them in time if they are loose.

IV. Notes

- . During installation, ensure that all components are tightly connected to prevent water leakage from affecting the internal environment of the RV.
- . Avoid severe impact on the sink to prevent damage to the stainless steel material.
- . The rubber pad has the functions of noise reduction and moisture prevention, so do not disassemble it at will.