

REPAIR SHEET

BRAND

RYOBI

DESCRIPTION


MODEL NO.

RY40PH01

MFG. NO.

317945002

40 Volt Power Head




TECHTRONIC INDUSTRIES POWER EQUIPMENT

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

1-22-24 (Rev:01)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



* Part comes as a complete assembly. Individual components of an assembly will not be offered separately, unless listed in the parts list.




RY40PH01

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
*1	205435010	Motor, Gear Box, Switch & Contact Plate Assembly	1
*2	314833001	Switch Trigger Assembly	1
*3	205032008	Boom Assembly (Inc. Key No. 6, 13-14 & 16)	1
*4	308991003	Front Handle Assembly (Inc. Key Nos. 17-18)	1
*5	205004007	Rear Handle Assembly (Inc. Key Nos. 9-12 & 15)	1
6	315386001	Boom Clamp Assembly	1
7	661864007	Screw (M4 x 18 mm, T15 Torx. Pan Hd.)	10
8	660005006	Screw (M3 x 10 mm)	2
9	570115001	Rubber Plate	2
10	941263373	Data Label	1


KEY NO.	PART NO.	DESCRIPTION	QTY.
11	941263370	Warning/Icon Label	1
12	941263369	Battery Statement Label	1
13	941263372	QR Label	1
14	941263388	Attachment Capable Label	1
15	940705496	Ryobi Logo Label	1
16	940779563	Harness Label	1
17	660643008	Screw	1
18	518949001	Wing Nut (1/4-20)	1
	Not Shown:		
	999000282	Operator's Manual	

* Part comes as a complete assembly. Individual components of an assembly will not be offered separately, unless listed in the parts list.

**WIRING DIAGRAM**

REPAIR SHEET

BRAND RYOBI		DESCRIPTION EXPAND-IT Straight Shaft Trimmer Attachment
MODEL NO. A54ST01	MFG. NO. 311247017	



TTI OUTDOOR POWER EQUIPMENT, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

1-12-24 (Rev:01)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



A54ST01

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	941588552	Max. Run Time/Performance Label	1
2	205033003	Straight Shaft Assembly (Inc. Key Nos. 3-5)	1
3	941263387	Lower Boom Icon Label	1
4	941851149	Ryobi Expand-it Label	1
5	941263402	Data Label	1
6	660738002	Screw (1/4-20 x 1-1/4 in., Hex Washer Hd.)	1
7	679958001	Compression Spring	1
8	205173008	Grass Deflector Assembly (Inc. Key No. 1 & 9-10)	1
9	638016007	Line Cut-off Blade	1
10	662148001	Screw (M4.5 mm x 1 mm, Pan Hd.)	2
11	660642001	Screw (1/4-20 x 1-1/4 in., Hex Washer Hd.)	1
12	660641001	Screw (10-24 x 5/8 in., Hex Washer Hd.)	1
13	678011001	Flanged Washer	1
14	308210009	Gear Head	1
15	205672002	Bump Feed Trimmer Head Assembly (Inc. Key Nos. 7 & 17)	1
16	638125001	Grass Deflector Clamp	1
17	941097129	String Head Logo Label	1
Not Shown:			
	999000343	Operator's Manual	

