




Replacement Parts List

Teapot 4 in. Centerset 2-Handle Low-Arc Bathroom
Faucet in Polished Chrome

MODEL	SKU #	FINISH
HD67092W-6301	102856	Chrome



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to [HOMEDEPOT.COM](https://www.homedepot.com), and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Index (C)	RP1000201	202666333	271685
2	Screw	RP50005		
3	Handle seat	RP1702701		
4	Retainer	RP1313601		
5	Handle (C)	RP13005	206131716	
6	Cap & Bolt	RP1300601		
7	Inverter	RP64044	206671349	
8	Bonnet nut	RP70193	206671342	
9	Washer	RP64123		

Part	Description	Part #	Internet SKU #	Store SKU #
10	Cartridge (H)	RP20067	301158139	
11	Cartridge (C)	RP20068	301158129	
12	Gasket	RP80182		
13	Mounting nut	RP56001	203193994	579276
14	Index (H)	RP1000101	202666333	271685
15	Handle (H)	RP13004	206131720	
16	Aerator	RP3021001		
17	ClickInstall™ drain assembly	RP4022801		
18	Lift rod	RP4020401		