



User Manual **HoHoHoH2O™ EZ Christmas Tree Watering System**
 To learn more about HoHoHoH2O™ EZ Christmas Tree Watering System visit www.hohohoh2o.com

IMPORTANT SAFEGUARDS

To reduce the risk of fire, electric shock and/or injury to persons, basic safety precautions should always be followed when using electrical appliances, including the following:

READ ALL INSTRUCTIONS BEFORE USING HOHOHOH2O™

- This unit is for indoor use only.
- Do not place unit on its side.
- Once filled with water, keep unit upright and minimize movement.
- **Do not overfill tank- do not fill to within 2 inches of top.**
- Make sure the water tube and sensor are securely attached to tree trunk before turning unit on.
- Make sure water tube and sensor are placed below the lip of the tree stand.
- Do not pull water tube from tank.
- Do not allow children to use as a toy.
- Do not stand on box to hang ornaments or star.
- Do not operate this product with a damaged cord or plug after product is dropped or damaged in any manner.
- Ensure electric cord, water tub and water sensor are fully under tree to avoid tripping and unit disturbance.
- Place unit directly on floor, ensuring a level surface.
- Do not place on other packages.
- Make sure tank opening is securely closed before turning on.
- Fill carefully, see instructions for care if overflow or splashing occurs.
- Fill tank with water only.
- Decorative box is for tank use only.
- Always plug cord into 120V three prong outlet. Do not modify plug in any way. Do not use a 3 to 2 prong adapter.


SAVE THESE INSTRUCTIONS

WELCOME

Congratulations on your purchase of HoHoHoH2O™ EZ Christmas Tree Watering System. Your holiday season has just gotten easier! Please read on for detailed instructions, product specs and more. For more information on HoHoHoH2O™ please visit us at www.hohohoh2o.com.

1. Power Cord
2. Water Sensor
3. Water Tube
4. Velcro Strap
5. Decorative Gift Box
6. Decorative Gift Box Lid (Bow not included)
7. Water Tank
8. Water Tank Lid
9. Control Panel
10. Spill Tray *not shown*

- a) On/Off Switch
- b) Power Light
- c) Light/Alarm Button
- d) Low Water Warning Light
- e) Low Water Warning Alarm



SPECIFICATIONS



AC 110-120V 60Hz 2.5 Gallons 13.5 x 10.4 x 9.5 inches 6.85 lbs.

LEARNING ABOUT YOUR HoHoHoH2O™

1. **Power Cord:** The 3-pin grounded power cord is 72 inches long
2. **Water Sensor:** The water sensor is 55 inches long
3. **Water Tube:** The water tube is 55 inches long. It is meant to be flush with the tip of the water sensor.
4. **Velcro Strap:** The 35 inch velcro strap securely affixes the tube and sensor to the trunk of the tree.
5. **Decorative Gift Box:** The decorative gift box houses the water tank for subtly while under the Christmas Tree. It measures 9.5 in (H) x 13.5 in (W) x 10.4 in (D).
6. **Decorative Gift Box Lid:** The decorative gift box lid fits perfectly atop the unit to cover the box and control panel.
7. **Water Tank:** The water tank holds 2.5 gallons of water and is affixed with a water pump to deliver water to the tree via the water tube.
8. **Water Tank Lid:** The water tank lid easily twists on and off and provides a large opening for a mess-free fill of the water tank.
9. **Control Panel:**
 - a) **On/Off Switch**
 - b) **Power Light:** Indicates power source and unit are functioning when on
 - c) **Light/Alarm Button:** When unit is OFF, press button to switch between the low water indicator of your choice; flashing light or beeping sound.
 - d) **Low Water Warning Light:** If "light alarm" option is chosen (default), a red light will flash when the tank is low on water. This will be visible via a hole in the decorative gift box lid.
10. **Spill Tray:** Spill tray provided to help prevent any spilled water from draining into gift box while filling the water tank.

HoHoHoH2O™ INSTRUCTIONS FOR USE

Please follow the instructions below to ensure proper use of HoHoHoH2O™ EZ Christmas Tree Watering System.

To watch an instructional video simply scan the QR code from your smartphone or visit www.hohohoh2o.com:



1. Place unit under the tree: ensure the unit is within 25 inches from the trunk/stand.
2. Attach water tube and water sensor to trunk using velcro fastener, making sure the bottoms of tube/sensor are 2-3 inches from the bottom of the stand.
3. Remove gift box lid.
4. Remove water tank lid.
5. Carefully fill the tank with up to 2.5 gallons water. **Do not fill to within 2 inches of top.**
6. Remove spill tray
7. Replace water tank lid.
8. Replace spill tray.
9. Plug HoHoHoH2O™ into an outlet.
10. Flip the switch.
11. Replace gift box lid.
12. Enjoy your fresh cut Christmas tree without the hassle!
13. To change the "low water indicator" from a flashing light to a beeping sound, simply hold button on panel while unit is off.

HoHoHoH2O™ INSTRUCTIONS FOR CARE

- This unit is for household use only.
- This system is designed for use with fresh cut Christmas trees affixed to a standard tree stand (per its instructions) and should not be used in any other applications.
- Ensure unit is turned off before unplugging or disassembling.
- When finished for the season, remove water tank from festive gift box. Empty any remaining water and dry completely before storing.
- Do not overfill tank. **Do not fill to within 2 inches of top.**
- If water should overflow, unplug unit, remove the tank from decorative gift box and dry completely before re-inserting.
- Once tank is filled, ensure the screw-cap is properly affixed to the unit before use.
- For best results, set up HoHoHoH2O™ in a convenient space under the tree.

LIMITED WARRANTY

Limited Warranty: Used with normal care, this Glad Tidings Products, LLC product is guaranteed against defective material and workmanship for a period (1) year from the date of original purchase ("Warranty Period"). We will repair or replace at our option, any product or part that is defective in material or workmanship without charge if the product is returned to us postage prepaid with dated receipt as proof of purchase within the Warranty Period. This warranty does not apply to commercial use or any product abuse. ALL IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE WARRANTY PERIOD. GLAD TIDINGS PRODUCTS, LLC SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow limitations on how long an implied warranty lasts and some states do not allow exclusions or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This Limited Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

For product questions contact:
www.hohohoh2o.com
info@hohohoh2o.com

Made in China

HoHoHoH2O™ EZ Christmas Tree Watering System is a registered trademark of Glad Tidings Innovations, LLC and related intellectual properties area under the jurisdiction of the US Patent Office.