



Important Assembly Bulletin

All LoCo griddles have hoods that are pre-attached to the griddle cooktop at the factory.

When removing the griddle hood & cooktop from the box, it must be removed by **LIFTING FROM THE BOTTOM OF THE GRIDDLE COOKTOP.**



DO NOT REMOVE THE GRIDDLE TOP FROM THE BOX BY LIFTING IT BY THE HANDLE.



Lifting by the handle will permanently damage the hinges and hood