
Outdoor ceiling fan
User's Manual



After-sales Email: support@fanlamppro.com

WARNING!!!

- **To avoid fire, shock and serious personal injury, follow these instructions.**

1. Read your user's manual and safety information before installing your new fan. Review the accompanying assembly diagrams.
2. Before servicing or cleaning the unit, switch off the power at the service panel and lock the service panel to prevent power from being switched on accidentally. If the service disconnecting means cannot be locked, securely fasten a warning device, such as a tag, to the service panel.
3. Be cautious around the fan and blades when clearing, repairing, or working near the fan. Always turn off the power to the ceiling fan before performing any servicing.
4. Do not insert anything into the fan blades while the fan is operating.
5. This appliance is not intended for use by young children or individuals with disabilities without supervision. Young children should be supervised to ensure they do not play with the appliance.
6. Before installing your ceiling fan, refer to the section on the proper method of wiring your fan. If you feel that you do not have enough wiring knowledge or experience, it is recommended to have your fan installed by a licensed electrician.


Before Installation

- **This manual is designed to make it as easy as possible for you to assemble, install, operate and maintan your ceiling fan.**


NOTE: Place the parts from the loose parts bags in a small container to keep them from being lost. If any parts are missing contact us.



Ladder



Screwdriver





Electric drill



Goggles




Accessories




● Check to see that you have received the following parts

2  Washer	2  Self-tapping screw	2  Expansion screw	3  Zip ties

Package Contents

● Check to see that you have received the following parts

1  Mount bracket	1  Downrods	1  Lampshade

1  Lamp Body	1  Coupling Cover	1  Remote Controller

Energy Saving Usage

- Ceiling fan performance and energy savings rely heavily on the proper installation and use of the ceiling fan. Here are a few tips to ensure efficient product performance.

Choosing the Appropriate Mounting Location

Ceiling fans should be installed or mounted in the middle of the room and positioned at least 7 feet above the floor.
If the ceiling height allows, it is recommended to install the fan 7~9 feet above the floor to achieve optimal airflow.

Turn Off When Not in the Room

If the room is unoccupied, turn off the ceiling fan to save energy.

Using the Ceiling Fan Year Round

Summer Season: Use the ceiling fan in the counterclockwise direction. The airflow created by the ceiling fan produces a wind-chill effect, making you feel cooler. Select a fan speed that provides a comfortable breeze; lower speeds consume less energy.

Winter Season: Reverse the motor and operate the ceiling fan at a low speed in the clockwise direction. This produces a gentle updraft, which pushes the warm air near the ceiling down into the occupied space. Remember to adjust your thermostat when using your ceiling fan. This simple step can lead to additional energy and cost savings.

Installation

Fig.1





Fig.2



- Carefully take out the lampshade from box to a stable palce, it is fragile.
- Use self-tapping screws to drive into the wooden ceiling.

Fig.3





Fig.4



- Drill a hole on the cement ceiling, then use expansion screws to secure.
- Take out the downrod pin of the 10" downrod assembly.

Fig.5





Fig.6



- Choose a downrod for the suspended installation. The recommended downrod length is 10 in.
- Install the coupling cover onto the downrod.

Installation

Fig.7





Fig.8



- Assemble the downrods and yoke as shown in the diagram, then insert the downrod pin, lock it with the downrod clip, and finally tighten the two screws on the yoke.
- Suspend the lamp on the Mount bracket.

Fig.9






Fig.10




- Move the Coupling Cover downwards.
- Screw the lampshade to the bottom plate.

Fig.11




- Plug in and operate with remote controller.

Remote Control




Wall Plate Installation

Attach wall plate using the two screws provided.



Installation Recommended

Room Size:



UP TO 8.5 ft x 8.5 ft

Trouble shooting

PROBLEM	SUGGESTED REMEDY
If Fan Does Not Start	1. Check if the remote controller is paired and battery is working. 2. Check the outlet is in good condition.
If The Fan Sounds Noisy	1. Make sure all screws in the yoke are snug. 2. Allow a “break-in” period of 24 hours. Most noises associated with a new fan will disappear after this period. 3. Check if the fan blades are in contact with the something.
If Fan Wobbles	1. Make sure that hook is scured. 2. Make sure all screws in the yoke are snug.
If Light Does Not Work	1. Check for loose wiring of the LED board.
Remote Does Not Work	1. Battery out of power or not installed correctly; change new AAA battery and ensure well installed. 2. Re-pairing the remotor by Long-pressing "2H" within 5s after plug in the outlet to pair.

Customer Service :

30-Days Full Refund Guarantee
If you are not completely satisfied or the item isn't what you expected, just tell us within 30 days. We will give you a full refund unconditionally.

Friendly Reminder
It's better to contact us than leaving a negative shopping experience. Nothing is more important than your satisfaction, and we will do our best to serve you.

Quick Response within 12 Hours
You can contact us without any hesitation at any time of the day, and we will reply to you within 12 hours. (It would be appreciated if you could provide us with a video or pictures, if available)

2-year Warranty
We will send you brand new items for free or give you a full refund if any quality problems occur within 2 years from the date of purchase.

Contact Information :

: You can contact us by sending an email to support@fanlamppro.com

GET MORE SUPPORT

If you encounter any issues while operating any of our products, you can directly contact us via email.