


Climber & Slide

USER MANUAL



READ AND SAVE THIS INSTRUCTION FOR FUTURE USE

SAFETY & WARNINGS

ADULT ASSEMBLY REQUIRED.

- Keep these instructions for future reference.
- This product is intended for indoor, outdoor, home, domestic use only. It is not suitable for commercial or medical use.
- The assembly of the product must be done carefully and by an able-bodied adult. If in any doubt, ask a technically qualified person.
- Ensure the installation area is ventilated.
- Do not use the product if it is damaged or defective. If it is damaged or defective, please contact a qualified technician.
- Check that all parts are assembled well and are stable before use. Defective parts must be changed immediately as they can impair the function and the safety of the product.
- Use the product only on even and non-slip surfaces. Keep sufficient space around for safety. Place in a well-lit room.
- Keep away from fire or any source of ignition.
- Packing materials are not toys, keep them away from children.
- Dress children appropriately: do not allow children to wear loose-fitting clothing including ponchos, scarves and garments with drawstrings. Well-fitting shoes must be worn at all times.
- Provide adult supervision at all times.


PLEASE DO NOT RETURN TO STORE




**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


PART LIST




Upper Climber x 2




Lower Climber x 2




A-Frame Side Panel x 3




Slide Handrail x 2




Slide x 1



buffer Board x 1




Platform x 1



Stair x 1



Basketball Ring x 1



Basketball Net x 1



Connect Bar x 1



Plastic Screwdriver x 1



Basketball x 1



Metal Screw A x 1



Screw B x 2



Screw C x 16



Screw D x 1




Screw E x 26



Square Screw F x 3




Screw G x 2




Non-Slip Pad x 3

ASSEMBLY




Step1

Connect the Slide and Buffer Board, secure with Screw A on the back. Attach the Non-Slip Pad under the Slide as shown for extra stability.




Step2

Connect the Handrails together with Screw G, and then attach the long Handrail to Slide, secure with 8pcs Screw C on each side, 16pcs in total. Tighten with Plastic Screwdriver.




Step3

Connect the A-Frame Side Panel with 1pc Square Screw F and 1pc Screw E on each set. Repeat the same to complete 3 sets in total.



Step4


Attach the Slide section to the A-Frame Side Panel, secure with 1pc Screw B.



Step5


Insert the Connect Bar into the hole at the bottom of A-Frame, secure with 1pc Screw E.

ASSEMBLY




Step6

Install the Platform, secure it to A-Frame with 2pcs Screw E.




Step7

Connect the stair and A-Frame Side Panel, secure with 1pc Screw E at the bottom.




Step8

Attach the second A-Frame to the section assembled, secure the with 4pcs Screw E.



Step9


Combine the Upper Climber and Lower Climber. No screw needed in this step.



Step10


Connect 1 Climber Panel with the 3rd A-Frame Panel, secure with 4pcs Screw E as shown.

ASSEMBLY




Step11

Repeat the same to attach the other climber to the A-Frame Panel, secure with 4pcs Screw E.




Step12

Connect the Climber section and the A-Frame Side Panel on the Slide section, secure with 7pcs Screw E.



Step13

Attach the Basketball Net to the Ring.



Step14

Install the Basketball Hoop on the A-Frame Side Panel, secure with Screw D.