


OPERATION INSTRUCTIONS:

Visit hydrotechproducts.com/getstarted for How to Videos

1. Ensure rubber washer is securely in place inside the hose end connection (coupler) before attaching the hose to the faucet (spigot). (Extra rubber washer is included)
2. Make sure the coupler and the close valve ends are both securely tightened to the hose.
3. Connect hose coupler to the water spigot.
4. Close valve at other end of hose.
5. Turn on the water and fill the hose to expand completely. Remember to reopen valve before use.



Operating pressure should be at least 60 PSI for maximum performance.

IMPORTANT INFORMATION:

1. Do not leave hose under full pressure when not in use.
2. In extreme heat, store hose indoors.
3. Do not leave hose outside in freezing temperatures, store indoors in the winter.

NOTICE: Hose retracts when the water source is turned off. Stand clear of any attached accessories that may be pulled toward the spigot.

WARNING

- Keep out of reach of children and pets.
- Strangulation hazard. Hose wrapped around neck may cause serious injury or death.
- DO NOT attach this hose to a sprinkler with a ground spike. Sudden water loss or hose damage may inadvertently cause the hose to rapidly retract.
- Improper use of this product may cause serious injury or death.
- DO NOT attempt to disassemble the hose. Any attempt to disassemble the hose may cause the hose to function improperly or may cause injury or death.
- This hose is NOT drinking water safe and shall not be used for transferring drinking/potable water.