




INSTRUCTION MANUAL

Grill Gazebo / LED

GENERAL BEST PRACTICES FOR ASSEMBLY

- Please read and understand this entire manual before attempting to assemble or install the product.
- Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.
- The assembled gazebo should be located at least 6 feet from any obstruction such as fence, garage, house, overhanging branches, laundry lines or electrical wires.
- Some parts may contain sharp edges. Wear protective gloves if necessary, during assembly.
- Check all nuts and bolts periodically for tightness and, when required, tighten them again.
- Pay attention to the parts orientation.

WARNINGS

- Install the gazebo on level ground. Stakes are provided to secure the gazebo to the ground.
- Do not assemble the gazebo on sandy, muddy, or loose soil, as stakes do not have enough anchorage in these types of soil.
- If you wish to secure the gazebo to a wood deck or concrete surface, use anchors (not included) suited to these surfaces.
- Snow must be cleared off regularly during snowy days.
- To avoid damage, use a plastic snow rake to remove excessive snow and ice buildup from roof and keep away from falling debris.
- Do not leave the gazebo where there is a risk of high wind, as possible damage will occur to the structure.
- Any assembly or maintenance of the product must be carried out by adults only.
- Please check your state and local regulations prior to purchasing. Some jurisdictions may require permits for installation and use. Some special procedures may be valid in your area.
- If any scratch paint, please touch up to prevent rusting.
- For outdoor use only.
- Keep all flame and heat sources away from this gazebo. This gazebo is made with fabric that meets CPAI-84 specifications for flame resistance. It is not fireproof. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the fabric may render the flame-resistant properties ineffective.

WARRANTY

WHAT IS COVERED?


The limited warranty is extended to the original purchaser and applies to material and manufacturer's defect provided the item is maintained with care and used only for personal, residential purposes.

Warranty: 1 Year


MAINTENANCE

- Steel components for this gazebo are treated with rust inhibiting paint that protects it from rusting. However, due to the nature of steel, surface oxidation (rusting) will occur if these protective coatings are scratched. This is not a defect and thus not covered by the warranty.
- To minimize this condition, it is recommended to use care when assembling and handling the product to prevent scratching the paint. Should any scratching or damage occur, it is recommended to cover the scratch immediately with rust inhibiting paint (not included).
- Surface rust can also be easily removed with a very light application of regular cooking oil or WD-40. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping onto deck or patio and caused damaging stains, which may be difficult to remove. This can be prevented if the above-mentioned measures are taken to keep the product from oxidizing.
- Do not use bleach, acid, or other abrasive cleaners on the roof or frame parts.
- Keep instruction manual for future reference.
- Keep the original packaging to store the gazebo.
- Periodically check and ensure that all bolts are well-tighten during use.


Tools Needed (Not Included)








Exploded Drawing





HARDWARE CONTENTS


No.	DESCRIPTION	Draft	QTY	EXTRA
AA	M6x20 Bolt		44	3
BB	Washer		52	3
CC	M6x35 Bolt		4	1
D	Nut		4	1
AndE	Wrench		1	0
FF	Stake		8	0

PACKAGE CONTENTS

No.	DESCRIPTION	Draft	QTY
A1	Right column		1
A2	Left column		2
A3	The Right column has a bottle opener		1
B	Large top oblique beam		4
C	Large top connector		1
D	Small top oblique beam		4
and	Long screen		2
F	Short screen		2
G	mesa		2
H	Tool hooks		1
I	Table connection sheet		4
I	Small top cloth		1
K	Large top cloth		1
L	Hooking		1
n	Nail the lid		4
the	Ground nail pieces		4
Q	LED 灯		4





Fx2




AAx3



BBx3





Ex2





AAx8



BBx8







Dx4




Jx1







X4



Gx2





Hx1



AAx12



BBx12



FF_{x8}