

Use and Care Manual

I. Introduction

Thank you for purchasing our Heavy - Duty Clothes Rack. This versatile and durable product is designed to meet your various clothing storage and display needs, whether at home or in a commercial setting.

II. Usage Instructions

A. Assembly

Carefully unpack the clothes rack components. Ensure all parts are present as per the packing list. You should have the metal tubes, hanging rods, bottom shelves, wheels, and assembly tools.

Assembly Steps:

First, insert the four height - adjustable metal tubes into the corresponding holes at the base of the rack. Make sure they are firmly in place. Attach the double hanging rods to the upper part of the metal tubes. Align the holes and use the provided screws and tools to tighten them securely. Install the bottom shelves onto the lower part of the metal tubes in a similar way. Finally, attach the four 360° omni-directional wheels to the bottom of the rack. Two of the wheels are lockable; for better stability, it is recommended to install the lockable wheels diagonally.

Height Adjustment: The clothes rack has four height - adjustable metal tubes. To adjust the height, loosen the locking mechanisms on the tubes (usually a screw or a clip - like device). Slide the tubes to the desired height and then tighten the locking mechanisms again. You can adjust both sides to different heights to hang different sizes of clothes.

Mobility and Locking

The rolling clothes rack is designed for easy movement. To move it, simply grasp the rack and push or pull it in the desired direction. The 360 ° wheels allow for smooth movement on most floor surfaces, including carpets, tiles, and hardwood. When you want to keep the rack in a fixed position, use the two lockable casters. Push down on the locking levers of the wheels to engage the locks. This will prevent the rack from sliding and ensure the safety of your clothes and the stability of the rack.

III. Care Instructions

A. Cleaning

Regular Dusting: Use a dry, soft cloth to regularly dust the clothes rack. This will keep it looking clean and prevent the accumulation of dirt, which could potentially scratch the electro - plated finish.

Deep Cleaning: For more thorough cleaning, dampen a soft cloth with mild soap and water. Gently wipe the surfaces of the rack, including the hanging rods, shelves, and metal tubes. Avoid using abrasive cleaners or scrubbers as they can damage the electro - plated finish, which protects the steel from rust and corrosion. After cleaning, dry the rack thoroughly with a clean, dry cloth.

B. Maintenance

Check for Loose Parts: Periodically check the connections between the parts, such as the screws holding the hanging rods and shelves. If you notice any loose parts, use the appropriate tools to tighten them immediately. This will maintain the structural integrity of the rack and prevent any potential accidents.

Avoid Overloading: While the rack has a high load - bearing capacity of 620LBS (400LBS on the double hanging rods and 220LBS on the bottom shelves), do not exceed these limits. Overloading can cause stress on the parts, leading to deformation or damage over time.

By following these use and care instructions, you can ensure that your heavy - duty clothes rack remains in excellent condition and serves you well for many years.

