

Special Notes for Wine or Beverage Refrigerator:

1. Plug the wine or beverage refrigerator into a grounded 3-prong outlet. Do not remove the grounding prong or use an adapter or extension cord
2. Read all instructions carefully for safe operation
3. Keep the wine or beverage chiller out of reach of children to prevent entrapment and suffocation hazards. Children should not operate, play with, or crawl inside the appliance
4. Before disposing of the old unit, remove the door but leave the shelves in place to prevent child access
5. Provide a dedicated circuit for the wine chiller to ensure proper electrical supply and prevent overloading
6. Upon arrival, please leave the unit upright and wait 24 hours before plugging it in
7. Avoid cleaning appliance parts with flammable fluids and keep flammable vapors and liquids away from the vicinity to prevent fire hazards
8. Disconnect the power line before performing any cleaning or maintenance tasks
9. Do not connect or disconnect the electric plug with wet hands to prevent electrical shock
10. Refer to a qualified technician for repairs or part replacements not recommended in the provided materials
11. Ensure two or more people handle the moving and installation process to prevent injuries
12. Install the wine refrigerator in a well-ventilated area, away from heat sources, wind, rain, water spray, or drips, with temperatures between 60.8 ° F (16 ° C) and 89.6 ° F (32 ° C)
13. Follow state and local codes for electrical, water, and drain connections during installation
14. Avoid using solvent-based cleaning agents or abrasives on the interior to prevent damage or discoloration