

# Before Starting:



Tame the Great Outdoors®

26" Two-Stage Snow Blower: YB6770

28" Two-Stage Snow Blower: YB7285

## QUICK-START INSTRUCTIONS

Follow these instructions to get your snow blower running quickly and correctly!



- 1. ADD OIL** (included) Oil has been drained for shipping. You **MUST** add oil before starting. Failure to do so will permanently damage your machine.



- 2. ADD FRESH GAS** If your machine has sat idle for more than 2 months, you should drain your gasoline tank and fill it only with fresh, new gas.



- 3. PLUG IN** the female end (a) of an extension cord into the receptacle outlet\* on your machine, and the male end (b) into a wall socket.

\* Plug receptacle is next to red start button  
Remove the cover to see the prongs -->



- 1 Fuel On**  
Open the Fuel Valve  
(Turn dial to ON)



- 2 Close Choke**  
Move Choke dial  
to CLOSED position



- 3 Throttle Up**  
Move the throttle to fast  
(Turn dial to FAST)



- 4 Prime It**  
If engine is COLD, press &  
release Primer Bulb 2-3 times



- 5 Key In**  
Insert Ignition Key



- 7 Open Choke**  
Return Choke dial to OPEN  
after engine is warm (~15-20s)



- 6 Press Start**  
Press the Start Button and hold  
in until engine starts, then release

