

Installation Instructions



[1]x2 Post

[2]x1Support

[3]x1 Support cover


[4]x2 Cap

[6]x8

[9]x12

m4.8x13mm
Flat Head Drill Screw

m8x60 *Expansion bolt*






[5]x2
Base plate cap

[7]90mmx2
Spacer

[10]x2

Support cap





[8]20mmx24

[11]x2




Brackets

[12]x4

m4.8x16mm
Flat Head Drill Screw



[13]x12 Slat panel



Step 1 Install post

Install spacer [8]




Install spacer [8]





[6]x4

[6]x4



Step 2 *Install panel*







[13]x12

Install spacer+panel one by one

Install spacer




Install cap [4]





[7]



Install cap [4]



[7]



Install support cover [3]x1

Install support

[9]x12

[2]x1

