

CONVENIENCE CONCEPTS

Care and Maintenance

With a little care and maintenance, you can prolong the life of your Convenience Concepts furniture. Follow the instructions below to ensure that it stays in the best shape for as long as possible. The information below is only intended as a general guideline.

To clean and care for your furniture:

- Use a soft, clean cloth that will not scratch the surface when dusting.
- Use of furniture polishes are not necessary. Should you choose to use polish, test first.
- Using solvents of any kind on your furniture may damage the finish.
- Never use water to clean your furniture as it may damage the finish.
- Use pads, cloth or felt to protect the furniture surface from hot dishes, beverages, and flowerpots.
- Liquid spills should be cleaned up immediately. Using a soft clean cloth, blot the spill gently and avoid rubbing.
- Do not drag or pull furniture as it may damage floor surfaces and the furniture.
- Check bolts or screws periodically and tighten them if necessary.