

SpeedTiles - Use & Care

Be sure your stove is installed according to manufacturer's standards before installing SpeedTiles as a range backsplash.

The SpeedTiles installed as a range backsplash can whitstand temperatures up to 93°C/ 199°F.

Never place the SpeedTiles in direct contact with an open flame.

The use of SpeedTiles is not recommended inside the shower or on a countertop.

