


Upson Single-Handle Touchless Pull-Down Sprayer Kitchen Faucet

MODEL	OMSID	SKU#	FINISH
HD67857-004405	314759889	1005808630	Matte Gold



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to [HOMEDEPOT.COM](https://www.homedepot.com), and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Spray head and Hose	RP384044405		
2	O-ring	RP60006		
3	Wearable Ring	RP64092		
4	Cartridge & Screw	RP20094		
4.1	Cartridge	RP20044	301158214	
5	Bonnet nut	RP70533		
6	Cap	RP800284405		
7	Handle assembly	RP136324405		
8	Escutcheon	RP806674405		
9	Gasket	RP80675		
10	Block	RP70421		
11	O-ring	RP60002		

Part	Description	Part #	Internet SKU #	Store SKU #
12	Quick connect assembly	RP70709		
13	O-ring	RP60089		
14	Weight clip	RP70609		
15	Weight	RP70525		
16	FastMount™	RP56096		
17	Pump kit	RP46022		
18	Flange kit	RP460414405		
19	Soap bottle	RP46024		
20	Soap dispenser kit	RP460824405		
21	Sensor control box	RP70708		
22	Battery pack	RP70707		