



Home Depot Item #

1007028899

1007028900


1007028898

1007028901

## APRON FRONT SINGLE BOWL KITCHEN SINK

---

### INSTALLATION INSTRUCTIONS USE AND CARE GUIDE



Questions, problems, missing parts? Before returning to the store,  
call Glacier Bay Customer Service  
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

**1-855-HD-GLACIER**



**[HOMEDEPOT.COM/GLACIERBAY](http://HOMEDEPOT.COM/GLACIERBAY)**

---

#### THANK YOU

*We appreciate the trust and confidence you have placed in Glacier Bay through the purchase of this sink. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Glacier Bay!*

PACKAGE CONTENTS



| PART | DESCRIPTION | QUANTITY |
|------|-------------|----------|
| A    | Sink        | 1        |



## SAFETY INFORMATION

---

Please read and understand this entire manual before attempting to assemble, operate or install this product.



### WARNING

- Keep all packaging materials out of the reach of children to prevent possible choking or suffocation.
- Use caution when installing the sink. There is a risk of crushing your fingers when inserting the sink into the installation location.

### CAUTION

- **NEVER** place hot objects such as hot pans on the sink. Wait until the object has cooled or use a heat resistant plate when placing hot objects on the sink surface.

### NOTICE

- Avoid leaving wet sponges, salt, and corrosive substances on the sink for long periods of time. Lines and scratches may be caused by improper use of the sink.
- **DO NOT** place the sink on its side as there is a risk of damage.

**KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

## PREPARATION

---

Before beginning installation of product, please inspect the product carefully for damage. Installation by a qualified and experienced professional is highly recommended.

Tools Required for Installation (not included): jigsaw, silicone sealant, safety goggles, pencil.

## INSTALLATION INSTRUCTIONS


### 1a. Preparing the installation location

If necessary, disconnect the water supply lines underneath the sink and remove the old sink.

If cabinet width allows for your farmhouse sink (A) to sit on left and right ledge, sit sink on cabinet and ensure that the sink (A) is pushed back and the cabinet walls sit flush against the sink ledge and apron.

Mark back edge of the sink (A). This will be used as a guide when cutting material from top of the cabinet walls so that the sink (A) can sit flush or slightly recessed (no more than 1/16").

**Note:** Use shims for minor adjustments in height and width.



### 1b. Preparing the installation location

If necessary, disconnect the water supply lines underneath the sink and remove the old sink.


If the cabinet width does not allow for proper support along the outer ledge of the sink (A), proper support frames must be installed.

Measure and cut wooden support beams and leave 5/8" (16mm) of space to the top of the cabinet as shown.

**Note:** Use shims for minor adjustments in height and width. A recommended space between the sink surface and the top of the cabinets should not exceed 1/16" (1.6mm).


**TIP:** C-clamps assist securing support frame to cabinet to aid installation with adhesive and proper wood screws.

Mark back edge of the sink (A). This will be used as a guide when cutting material from top of the cabinet walls so that the sink (A) can sit flush or slightly recessed (no more than 1/16").



### 2. Mounting the sink

Apply silicone sealant around the perimeter of the top of sink and place the countertop into position.



## CARE AND MAINTENANCE

---

- Do not use abrasive cleaning creams or powders, concentrated caustic soda, formic acid, or anything highly corrosive. For more information on removing difficult stains, contact Customer Service at 1-866-439-9800.
- Clean with a sponge or soft dish cloth and gentle sink soap. For stains that are difficult to remove, such as calcium deposits, use eraser sponges, vinegar-based cleaners, and lime removers.
- Rinse the sink with hot water and dry the sink with a soft absorbent cloth.
- Fruit juices, coffee, and tea can stain the surface of your sink if not removed. Rinse or wipe the sink promptly after these substances make contact with the sink.
- Never use steam or high-pressure cleaning systems to clean your sink.

## WARRANTY

---

### Limited Lifetime Warranty

This limited lifetime warranty warrants this item against defects in materials and workmanship.

This warranty applies only to the original purchaser. This warranty does not apply to any damage on the product by accident, misuse, or modified, improper installation or by affixing accessories not produced by the manufacturer. The manufacturer is not accountable whatsoever for product installation during the warranty period. There is no further expressed warranty. The manufacturer shall not be legally responsible for incidental, consequential or special damages arising at or in connection with product use or performance except as may otherwise be accorded by law. The manufacturer disclaims any and all implied warranties.





Questions, problems, missing parts? Before returning to the store,  
call Glacier Bay Customer Service  
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

**1-855-HD-GLACIER**

**[HOMEDEPOT.COM/GLACIERBAY](https://www.homedepot.com/glacierbay)**

Retain this manual for future use.