LED Light Kit

BUC11567

JOHN DEERE

INSTALLATION INSTRUCTIONS

LED Light Kit


UC34324 28MAR23 (ENGLISH)

Z315E, Z320M, Z320R, Z325E, Z330M, Z330R, Z370R
Residential ZTrak Mowers

John Deere Horicon Works
UC34324 (28MAR23)
PRINTED IN U.S.A.
COPYRIGHT © 2023
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRUCTION ™ Manual
Previous Editions
Copyright © 2012, 2022

UC34324-19-28MAR23

Download Instructions



Instructions, manuals, and other documents may be downloaded at www.techpubs.deere.com. Scanning the QR code on a mobile device will route to the site automatically.
Les instructions, les manuels et autres documents peuvent être téléchargés à cette adresse: www.techpubs.deere.com. Scanner le QR code via un appareil mobile mène automatiquement au site.
Istruzioni, manuali e altri documenti possono essere scaricati su www.techpubs.deere.com. La scansione del codice QR su un dispositivo portatile indirizza automaticamente al sito.
Anleitungen, Handbücher und andere Dokumente können unter www.techpubs.deere.com heruntergeladen werden. Durch Scannen des QR-Codes mit einem Mobilgerät wird man automatisch zur Webseite weitergeleitet.
Las instrucciones, los manuales y otros documentos se pueden descargar en www.techpubs.deere.com. Al escanear el código QR en un dispositivo móvil, se abrirá automáticamente el sitio web.
Instruções, manuais e outros documentos podem ser baixados em www.techpubs.deere.com. A leitura do código QR em um dispositivo móvel levará você automaticamente para o site.
Инструкции, руководства и другие документы можно загрузить на странице www.techpubs.deere.com. Сканирование QR-кода на мобильном устройстве будет автоматически отправлять на сайт.

TS1746 —UN—26APR21

DX,DOWNLOADINSTRUCTIONS,AT -19-27APR21-1/1

Parts in Kit

Quantity	Description
1	Right Light Assembly
1	Left Light Assembly
2	Screw, Self Tapping
1	Wiring Harness


NOTE: Retain these installation instructions with your machine operator's manual.

h2ac9y3,1655290026786 -19-15JUN22-1/1

Prepare Machine

1. Park machine safely. (See Parking Safely in machine Operator's Manual.)
2. Lift the front end of the foot plate (A).
3. Using both hands, pull the foot plate out of the two openings (B) in the frame.

A—Foot Plate **B—Two Openings**




GX536025 —UN—25APR22

czhk963,1678464361099 -19-10MAR23-1/2

4. Tip seat (A) forward.
5. Remove storage cover (B).

A—Seat **B—Storage Cover**



MXT004437 —UN—05JUN12


czhk963,1678464361099 -19-10MAR23-2/2

Install Wiring Harness


1. Route connector (A) on light wiring harness through hole, as shown. Connect wiring harness (B) that is under storage compartment cover onto light wiring harness connector (A).
2. Install storage compartment cover and lower seat.

A—Connector, Light Wiring Harness

B—Connector, Main Wiring Harness



MX102500 —UN—15JUN22




MXT004439 —UN—05JUN12

Continued on next page

h2ac9y3,1655291390405 -19-20JUN22-1/3

3. Route the light harness (A) along the side and front rails of the mower deck and secure with six plastic clips (B) on harness into holes in frame.

A—Light Harness **B—Plastic Clip (6)**




MX102501 —UN—15JUN22

h2ac9y3,1655291390405 -19-20JUN22-2/3

4. Screw in the threaded clip (A) to side rail of the mower deck under right light assembly.

A—Threaded Clip




MX102502 —UN—15JUN22

h2ac9y3,1655291390405 -19-20JUN22-3/3

Install Light Assembly

1. Install right light assembly by positioning on right corner of the mower deck with self tapping screw (A).
2. Attach penny LED plug (B) on wire harness to penny LED light on light assembly.
3. Attach 3 bar LED plug (C) on wire harness to 3 bar LED light on light assembly.
4. Repeat steps for left side light assembly.
5. Replace foot plate back on machine by pushing the back end of the foot plate back into the two openings on the frame. Then slowly lower front end of the foot plate onto the frame.

A—Self Tapping Screw
B—Penny LED Light Plug
C—3 Bar LED Light Plug



MX102503 —UN—15JUN22

Light Assembly

h2ac9y3,1655293919004 -19-20JUN22-1/1