Installation & User Guide – Garden Shears Set

Product Overview

- Garden shears set includes 30 in. anvil lopper with 2 in. cutting capacity, bypass pruning shear, and spare lopper blade.
- Anvil lopper features ratchet mechanism for maximum cutting power with minimal effort.
- Bypass pruner designed for stems and light branches with carbon steel blade.
- Ergonomic steel handles with soft grips for durability and comfort.

What’s Included

- 1 × 30 in. ratchet anvil lopper
- 1 × Bypass pruning shear
- 1 × Spare lopper blade

Before You Begin

- Wear safety gloves and eye protection during use.
- Inspect blades for sharpness and ensure fasteners are tight.
- Check handles and grips for secure attachment.

Assembly & Setup

- Tool is pre-assembled; no major assembly required.
- To replace lopper blade: remove securing bolts with wrench, install spare blade, and tighten bolts firmly.
- Apply light oil to blade pivot before first use.

How to Use the Anvil Lopper

- Position blade jaw around branch up to 2 in. diameter.
- Squeeze handles together; ratchet mechanism will engage for easier cutting.
- Repeat motion until branch is cut completely.

How to Use the Bypass Pruner

- Ideal for trimming stems and light branches.
- Place blade at desired cutting point and squeeze handles together for clean cut.
- Wipe blade clean after each use.

Care & Maintenance

- Clean soil and sap from blades after each use; dry thoroughly.
- Apply light machine oil to pivot points and blade edges to prevent rust.
- Sharpen blades with a file or sharpening stone as needed.
- Store in dry location away from moisture.
- Replace with included spare lopper blade when original becomes dull or damaged.

Troubleshooting

- Difficulty cutting → sharpen or replace blade; ensure ratchet mechanism is clean.
- Handles slipping → check grip condition; wear gloves.
- Loose blade → tighten pivot bolt or replace blade if worn.