

INSTALLATION GUIDE

MULTI-HEAD RECESSED GIMBAL 5 CCT CHANGE LR32180, LR32183, LR32185

⚠ WARNING

TURN THE POWER OFF FROM ELECTRICAL PANEL BEFORE INSTALLATION OR MAINTENANCE.

- DO NOT MODIFY THIS FIXTURE. ANY MODIFICATIONS MAY RENDER THE PRODUCT UNSAFE AND VOID WARRANTY.
- THIS PRODUCT IS SUITABLE FOR WET LOCATIONS

FIXTURE INSTALLATION

- STEP 1.** Measure distance from walls and mark position of fixture to be installed on the ceiling.
- STEP 2.** Carefully scribe hole template in accordance to cut hole size on desired location.
- STEP 3.** Carefully cut hole in ceiling. (Fig. 1)
- STEP 4.** Electrical connections.
- STEP 5.** Select Color Temperature
- STEP 6.** Connect hardwire box to engine by connecting the quick male and female connector. (Fig. 2)
- STEP 7.** Pass the hardwire box and attached bx cable through the hole and place on straight surface inside the ceiling cavity. (Fig. 3)
- STEP 8.** Push the spring clip up towards the LED engine. (Fig. 4)
- STEP 9.** Push the fixture through the hole until the trim is flush with the ceiling. Spring clip will retract to hold trim in place.

