

Adjust the white slide around the tines by sliding it up or down until the spacing of the tines matches the spaces in the fins. Starting a few inches above or below the problem area, comb through the bent fins slowly and carefully a few fins at a time. If needed, adjust the spacing as you are working through the damaged area to find the best position. Do NOT twist while combing through the fins as this will cause additional damage.