

SOLAR AIR PLIMP KIT FOR FISH POND - G3035

Features:

- The system is designed for oxygenating the water to create a healthy environment in any outdoor water body that keeps fish, such as outdoor aguarium, garden pond, and garden water feature.
- The air pump is powered by a solar panel. In order to make the pump work by solar energy, the solar panel needs to be placed in the sunlight with its solar cells facing the sun as much as possible.
- The performance of the pump depends on the sunlight intensity and the incident angle at which sunlight strikes the panel surface.
- There is no on or off switch available to start and stop the pump. Whenever the pump and the solar module are connected to each other, the pump operates if there is enough sunshine.

Assembling:

- 1. Roll out the air hose as well as the connection cable on the pump.
- 2. Fit the hose to the connector of the spring stone.
- 3. Connect the other end of the hose to the air outlet of the pump.
- 4. Place the pump on a dry and safe place near the pond. The place to hold the air pump should be higher than the water level to prevent the water from flowing back into the pump through the hose when the pump is not in operation.
- 5. Put the two pieces of the ground spike together and mount it on the back side of the solar module with the gland nut.
- 6. Mount the solar module in a sunny place by the ground spike and face the solar panel towards the sun.
- 7. Insert the plug of the pump to the socket of the solar module and screw the cap tightly.

Note: Don't dip the pump in water, it is not waterproof.

Note: The pump sucks in the air from the four rectangle orifices on the bottom shown in the right photo. Please make sure the air passage is not blocked.


Cautions:

- 1. Don't expose small components, such as spring stone, to little kids since they may swallow the small components and therefore be suffocated.
- 2. Please lay the connection cable properly so that it will not trip people.
- 3. Please mount the solar module firmly so that it will not fall down easily.
- 4. Do not strike the solar panel.

Cleaning The Pump

There is no need to maintenance the solar air pump regularly except the following two items:

- 1. Keep the surface of the solar module clean and wipe it with soft and moist cloth when necessary.
- 2. Check the spring stone from time to time and replace it with a new one if the spring stone is blocked.



Components:

- (1) Solar panel
- (2) Air pump
- (3) Air hose
- (4) Spring stone

Specifications:

Solar module:

Power: 1.5 Wp

Nominal voltage: 7.68 V Nominal current: 195 mA Safety class: IP 44

Air pump:

Operating voltage: DC 8V Flow rate: max. 2 LPM

Max. air pressure: >450 mmHg

Safety class: IP 44 Cable length: 3 m Hose length: 2 m

Set Includes:

Solar panel Air pump Air hose Spring stone Instructions

