

## Maintenance Schedule

- Before each use, always check for any worn, loose or damaged parts on the MoJack PRO. If any damaged parts are present, do not use the MoJack PRO and contact MoJack at 1-877-575-3173.
- Check the Lifting Strap before every use. Make sure the Lifting Strap is not damaged or torn and the stitching on the loop is secure. If any of these issues are present, do not use the MoJack Pro and call MoJack at 1-877-575-3173.
- Check that the Safety Ratchet is working properly. As the Carrier raises, the clicking sound indicates that the Safety Ratchet is functioning properly. Raise the Carrier to the working height and rotate the Winch Handle counter-clockwise 1/2 turn to release the tension off of the Lifting Strap. If the Carrier does not rest firmly into the Safety Ratchet and tension remains on the Lifting Strap, do not use the MoJack Pro and call MoJack at 1-877-575-3173.
- Place lithium grease on the small cog of the winch and between the small cog on the winch and the braking mechanism, and teeth and bolt of safety bar once a year or every 50 uses.

