

## Cycle/Option Guide

The cycle guide below shows the available options for each cycle.

### For Non-Steam Models

Cycle	Auto	Heavy	Delicate	Normal	Turbo	Express	Rinse	Machine Clean
<b>Soil Level</b>	all levels	heavy	light	all levels	heavy	light	light	
<b>*Water Usage</b>	13.1- 21.1 L	20.3 L	19.7 L	9.2- 19.5 L	27.5 L	20.4 L	6.8 L	12.3 L
	3.4- 5.6 gal	5.4 gal	5.2 gal	2.4- 5.2 gal	7.3 gal	5.4 gal	1.8 gal	3.2 gal
<b>**Wash Time w/o Options (Mins.)</b>	88 - 128	120 - 150	80 - 98	93 - 143	59	33	12	82
<b>Available Options</b>	<b>Dual Zone</b>	○	○		○	○		
	<b>Half Load</b>	○	○	○	○			
	<b>***Energy Saver</b>	○		○	○			
	<b>High Temp</b>	○	○		○	○	○	
	<b>Extra Dry</b>	○	○	△	○	○	○	
	<b>Night Dry</b>	○	○	○	○	○	○	
	<b>Delay Start</b>	○	○	○	○	○	○	○

\* Actual water consumption will vary depending on soil level and hardness of water.

\*\* Actual cycle times may vary depending on options chosen, soil level, water temperature, and hardness of water.

\*\*\* Energy Saver cannot be used at the same time as Extra Dry or High Temp.

△ : Extra drying time only, no added high-temperature rinse.

#### NOTE

- Options are not available for Download Cycle.

## For Steam Models

Cycle		Auto	Heavy	Delicate	Refresh	Normal	Turbo	Express	Rinse	Machine Clean
Soil Level		all levels	heavy	light		all levels	heavy	light	light	
*Water Usage		14.9-22.9 L	22.1 L	21.5 L	7.8 L	9.2-19.5 L	27.5 L	20.4 L	6.8 L	13.6 L
		3.9-6.0 gal	5.8 gal	5.7 gal	2.1 gal	2.4-5.2 gal	7.3 gal	5.4 gal	1.8 gal	3.6 gal
**Wash Time w/o Options (Mins.)		104 - 145	132 - 160	93 - 109	41	93 - 143	59	33	12	101
Available Options	Dual Zone	○	○			○	○	○		
	Half Load	○	○	○		○				
	***Energy Saver	○		○		○				
	Pre-Steam	○	○	○		○				
	High Temp	○	○			○	○	○		
	Extra Dry	○	○	△	△	○	○	○		
	Night Dry	○	○	○	○	○	○	○		
	Delay Start	○	○	○	○	○	○	○	○	○

\* Actual water consumption will vary depending on soil level and hardness of water.

\*\* Actual cycle times may vary depending on options chosen, soil level, water temperature, and hardness of water.

\*\*\* Energy Saver cannot be used at the same time as Extra Dry, High Temp or Pre-Steam.

△ : Extra drying time only, no added high-temperature rinse.

### NOTE

- Options are not available for Download Cycle.