

Installation Guide

1.5 in. Sump Pump Check Valve

Model: CH-150S-150MT




Package Contents

2 x Clamps →

Pipe Adapter →

Check Valve Body →



Tools Required



Safety Goggles



Tape Measure



Hacksaw



Flathead Screwdriver

Installation:

NOTE: For use with residential sump pumps only. Maximum 12 PSI.

1. Unplug your pump.
2. Remove the basin cover
3. Loosen check valve clamps and disconnect the discharge pipe at the check valve
4. Wrap new check valve threads with plumbers tape
5. Lift pump out of basin, remove old check valve and install new check valve
6. Place pump with new check valve back into the basin
7. Re-connect discharge pipe - be sure to tighten check valve clamps
8. Replace cover
9. Plug in pump
10. Cycle pump by pouring in water to check for leaks at check valve - if leaking, re-tighten clamps

Safety Information:



WARNING: Always disconnect power to your pump and release system pressure before servicing.

Warranty: For more information please visit our website: www.jackelinc.com/warranty