

Use and Care Manual

Installation: Expand the wooden frame. Attach one side of the desktop to the buckle. Unfold the desktop across the frame. Secure the opposite side by snapping it onto the buckle.

Installation Notice: The desktop panels are connected by durable elastic bands, allowing for flexible setup.

Usage Notice: The maximum load capacity is 77 pounds (35 kilograms). Please do not overload it to avoid damaging the table or causing potential safety hazards.

Cleaning: After use, promptly clean up food residues, stains, etc. on the desktop. You can wipe the desktop with a mild cleaner and a damp cloth, and then dry it with a dry cloth. Avoid using overly sharp or rough cleaning tools to prevent scratching the desktop.

Inspection: Regularly check the structural components of the table, including the frame, buckles, elastic bands, etc., to ensure they are firmly connected and there is no looseness or damage. If any damaged components are found, please replace or repair them in a timely manner.

Storage: When not in use, please fold the table and store it in a dry and ventilated place. Avoid exposing it to a humid environment for a long time to prevent the wood from getting damp, deforming, or rotting.