

Step 1 ATTACH 2 ACCU-HANGERS RANDOMLY. Press to make marks and install nails straight in marks leaving heads out 1/8"

Step 2 REMOVE TABS. Picture hangs straight even when Accu-Hangers are not. Use nail to remove tabs twisting down then up

Step 3 HANG YOUR PICTURE like a Genie