

Garbage Disposal Assembly - Fits In-Sink-Erator

Installation Instructions

No tools required for installation. Push Garbage Disposal Assembly into existing disposal rim until flange is seated against the rim. Periodically remove any collected waste from strainer.