

Use and Care Guide

METAL 550 LUMEN LED SPIKE LIGHT

Safety Information

Please read and understand these instructions before attempting to install or use this light fixture.

1. This LED fixture is suitable for outdoor use and wet locations.
2. Do not disassemble this LED fixture. There are no user-serviceable parts inside. The LED bulb is not replaceable.
3. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



WARNING: Risk of Fire, Electric Shock, or Injury to Persons. Turn the power off at the circuit breaker or fuse and install in accordance with local electrical codes.



WARNING: Do not install near flammable material.

Pre-Installation

NO TOOL REQUIRED.

Please clear the area for installation (above and 10 inches under ground) from hard objects.

For best result, moist the soil from the surround area for easier installation

5-Year Limited Warranty

WHAT IS COVERED

This product is guaranteed to be free of factory defective parts and workmanship for a period of 5 years from date of purchase. Purchase receipt is required for all warranty claims.

WHAT IS NOT COVERED


This guarantee does not include repair service, adjustment and calibration due to misuse, abuse or negligence, or LEDs. Unauthorized service or modification of the product or of any furnished component will void this warranty in its entirety. This warranty does not include reimbursement for inconvenience, installation, setup time, loss of use, unauthorized service, or return shipping charges. No service parts are available for this product.

Contact the Customer Service Team at 1-877-527-0313 or visit www.homedepot.com.

Installation


1 PLACING THE SPIKE LIGHT

- Hold the light by the base of the spike and gently push the spike into the ground. The (A) flat base of the spike should be at ground level when finished and the spike should be vertical. In rocky or hard packed dirt, use a small shovel to dig up rocks and loosen the soil. Place the spike(A) in the ground and pack the dirt in and around it to secure it.




2 CONNECTING TO POWER SOURCE

- Plug the power cord (B) into a grounded and GFCI-protected three-prong extension cord or the wall outlet.



3 AIMMING THE SPIKE LIGHT

- Ensure the power is off. Loosen the adjustment screw (C) on the side of the light, tilt the fixture up or down. Tighten the adjustment screw (C). Restore power. Repeat this step until the desired angle is achieved.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Guía de uso y cuidado

550 Lumen Lamapara Led Tip'Estaca

Información de seguridad

Lea y comprenda todas las instrucciones antes de intentar instalar o usar esta lámpara.

1. Esta lámpara LED es apta para uso exterior y en ubicaciones húmedas.
2. No desarme esta lámpara LED. No hay piezas que el usuario pueda reparar dentro.
No se puede reemplazar la bombilla LED.
3. Este equipo cumple con la parte 15 de las reglas de la FCC. El funcionamiento está sujeto a las siguientes dos condiciones: (1) este dispositivo no puede causar interferencia dañina, y (2) este dispositivo debe aceptar toda interferencia recibida, incluso la que puede causar un funcionamiento indeseado.

ADVERTENCIA: Riesgo de incendio, descarga eléctrica o lesiones. Apague la alimentación del disyuntor o fusible e instale de acuerdo con las normas eléctricas locales.

ADVERTENCIA: No instalar cerca de material inflamable.

Preinstalación

NO se requiere ninguna herramienta.

Por favor despeje la zona de la instalación de objetos duros. (por encima del suelo y 10 pulgadas debajo de la superficie)

Para obtener el mejor resultado, humedezca el suelo del área circundante para facilitar su instalación.

Garantía Limitada Por 5 Años

QUÉ ES LO QUECUBRE

Este producto está garantizado contra piezas defectuosas de fábrica y mano de obra por un período de 5 años a partir de la fecha de compra. El recibo de compra es necesario para todos los reclamos de garantía.

QUÉ ES LO QUENOCUBRE


Esta garantía no incluye servicio de reparación, ajuste y calibración debido al mal uso, abuso o negligencia, o los LED. El servicio no autorizado o la modificación del producto o de cualquier componente proporcionado anularán esta garantía en su totalidad. Esta garantía no incluye reembolso por inconvenientes, instalación, tiempo de preparación, pérdida de uso, servicio no autorizado o gastos de envío de devolución. No hay piezas de repuesto disponibles para este producto.

Comuníquese con el equipo de Atención al Cliente al 1-877-527-0313 o visite www.homedepot.com.

Instalación


1 COLOCAR LA LUZ LED

- Mantenga la luz en la base de la punta y empuje suavemente la punta en el suelo. La base plana (A) de la punta debe estar a nivel del suelo cuando haya terminado y la punta debe estar vertical. En terreno rocoso o compacto, use una pala pequeña para desenterrar rocas y aflojar el suelo. Coloque la punta (A) en el piso y empaquete la suciedad para asegurarla.




2 CONEXIÓN A LA FUENTE DE ENERGÍA

- Enchufe el cable de alimentación (B) en un cable de extensión de tres patas con conexión a tierra y protegido contra GFCI o en la toma de corriente de la pared.



3 APUNTANDO A LA LUZ LED

- Asegúrese de que la energía esté apagada. Aflojar el tornillo de ajuste (C) en el lado de la luz, inclinación el dispositivo hacia arriba o hacia abajo. Apretar el tornillo de ajuste (C). Restaurar el poder Repita este paso hasta que se logre el ángulo deseado



Nota: este equipo ha sido probado y se ha encontrado que cumple con los límites para un dispositivo digital de clase B, de acuerdo con la parte 15 de las reglas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias dañinas en una instalación residencial. Este equipo genera, utiliza y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencia perjudicial a las comunicaciones por radio. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación en particular. Si este equipo causa interferencias dañinas a la recepción de radio o televisión, lo cual puede determinarse apagando y encendiéndolo el equipo, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas:

- permite reorientar o reubicar la antena receptora.
- aumente la separación entre el equipo y el receptor.
- Conecte el equipo a una toma de corriente de un circuito diferente al que está conectado el receptor.
- Consulte al distribuidor o a un técnico experimentado en radio/TV para obtener ayuda.

PRECAUCIÓN: los cambios o modificaciones no aprobados expresamente por la parte responsable del cumplimiento podrían anular la autoridad del usuario para operar el equipo.