

Use and Care Manual

Usage Guidelines

Hooks: Use the 5 double metal hooks to hang coats, jackets, hats, towels, purses, robes, backpacks, or other items. Each hook can hold up to 10 lbs (4.5 kg).

Shelf: The shelf is perfect for displaying decorative items such as photo frames, potted plants, or small decor. It can also hold lightweight items like keys, wallets, or coffee mugs.

Weight Limit: Do not exceed a total weight of 30 lbs (13.6 kg) on the shelf and hooks combined.

Care and Maintenance

Wood Surface: Wipe with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.

Metal Hooks: Clean with a dry or slightly damp cloth. For stubborn stains, use a mild soap solution and dry immediately.

Avoid Moisture: While the product is durable, prolonged exposure to moisture may damage the wood. Wipe off any spills or water immediately.

Inspect Regularly: Check the screws and mounting brackets periodically to ensure they remain tight and secure.

Avoid Overloading: Do not exceed the recommended weight limits to prevent damage to the product or wall.

Safety Precautions

Ensure the shelf is mounted securely to avoid accidents. Do not hang heavy or sharp objects that could damage the hooks or shelf. Keep out of reach of children to prevent injury from falling objects. Do not use the shelf as a step stool or support for climbing.

Troubleshooting

Loose Shelf: Tighten the screws or reposition the shelf using additional wall anchors.

Scratches on Wood: Use a wood touch-up pen or polish to minimize the appearance of scratches.

Rust on Metal Hooks: Gently sand the affected area and apply a rust-resistant coating.