

Introduction

Thank you for purchasing our patio swing. To ensure your swing lasts for many years, please follow the instructions provided in this manual. This manual covers assembly, use, and care guidelines.

Table of Contents

1. Safety Instructions
2. Assembly Instructions
3. Usage Guidelines
4. Maintenance and Care
5. Troubleshooting
6. Warranty Information
7. Contact Information

1. Safety Instructions

- **Weight Limit:** Ensure the swing is not overloaded. The maximum weight capacity is 500 lbs.
- **Stable Surface:** Place the swing on a flat, stable surface to prevent tipping.
- **Supervision:** Children should be supervised while using the swing.
- **Weather Conditions:** Do not use the swing during extreme weather conditions (strong winds, heavy rain, snow).

2. Assembly Instructions

Tools Required

- Adjustable wrench
- Phillips screwdriver
- Rubber mallet (optional)

Parts List

- Frame components
- Swing seat
- Canopy
- Bolts, nuts, and washers
- Cushions (if included)

Steps

1. **Frame Assembly:**
 - Attach the base frame pieces together using bolts and nuts. Ensure all connections are secure.

- Attach the legs to the base frame. Tighten all bolts.
- 2. **Swing Seat Assembly:**
 - Attach the seat frame to the main frame.
 - Secure the seat using the provided bolts, nuts, and washers..
- 3. **Final Check:**
 - Ensure all bolts are tight and the swing is stable.

3. Usage Guidelines

- **Seating:** Ensure users sit evenly on the swing to avoid tipping.
- **Cleaning:** Clean the swing regularly using a mild detergent and water. Avoid harsh chemicals.

4. Maintenance and Care

- **Regular Inspections:** Check all bolts and nuts periodically to ensure they are tight.
- **Weather Protection:** Cover the swing or store it indoors during harsh weather conditions.
- **Fabric Care:** Remove and clean cushions and canopy as needed. Follow the washing instructions on the fabric labels.

5. Troubleshooting

- **Swing Squeaking:** Apply a small amount of lubricant to the joints.
- **Swing Not Level:** Ensure the swing is placed on a flat surface. Adjust the legs if necessary.
- **Canopy Issues:** Check that the canopy is properly attached and not damaged.

6. Warranty Information

This product comes with a one-year limited warranty against manufacturing defects. Proof of purchase is required for warranty claims.

7. Contact Information

For questions, replacement parts, or warranty claims, please contact us:

- **Email:** m_ferdinand01@outlook.com
- Following these guidelines, you can ensure your patio swing remains a comfortable and enjoyable part of your outdoor space for many years.