

INSTALLATION

- Install the product near an easily accessible electrical outlet.
- Do not install the product on an uneven or inclined surface.
- Do not install the product in a damp area and keep away from splashing rain or water.
- Do not install the product in an area exposed to direct sunlight or near heat-generating equipment.
- Do not install the product in a place where combustible gas may leak or industrial oil or metallic particulates are present.

POWER

- This product is designed to use a standard 115 V, 60 Hz outlet. Always check the supply voltage before using it.
- Make sure the product does not pinch or crush the power cord or plug.
- Unplug the product before cleaning it or replacing the filter.
- Do not touch the power plug with wet hands.
- Make sure the plug is clean and dry before plugging it firmly into the outlet.
- When unplugging the power cord, always pull it by the plug.
- Unplug the product during electrical storms or when not in use for a long time.

- Do not bend the power cable excessively or place a heavy object on top of it.
- Do not extend the length of the power cable or alter it.
- Do not use several devices on a multi-socket extension outlet.
- Unplug the product before cleaning or attempting any user maintenance. Turning the controls to the OFF position does not disconnect the appliance from the power supply.
- Take care to ensure that the power cable cannot be pulled out or damaged during operation. There is risk of fire or electric shock.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.

USE

- If the product is submerged in water, stop using it and contact the LG Service Center.
- If there is a gas leak (isobutane, propane, LNG, etc.), do not touch the product or power plug and ventilate the area immediately.
- Do not use abrasive or metal brushes, cloths or sponges to clean the product.
- If you detect any abnormal noise, odor or smoke, unplug the product immediately and contact an LG Service Center.
- Only an LG Electronics authorized repair person should disassemble, repair, or modify the product.

- Do not use the product near an open flame. Do not use or store combustible or flammable substances near the product, such as ether, benzene, alcohol, drugs, propane, butane, combustible sprays, insecticide, air freshener, cosmetics, candles, and lamps.
- Do not place the power cord under rugs, carpeting or mats.
- Do not allow animals or pets to chew on the power cord.
- Do not allow children to climb on or play with the product.
- Do not move the product when it is in operation.
- Do not place objects or containers on top of the product.
- Do not insert hands or metal objects into the air inlet or outlet.
- Do not impact the product.
- To avoid injury, take care around pinch points when detaching or reattaching product parts.
- Unplug the product when not in use for a long time.
- Do not install or use broken parts.
- Unplug the product before cleaning it.
- Do not put flammable substances into the product.
- Do not operate the product while its cover is open.
- Do not swallow the battery. It may cause injury, including damage to internal organs, or death.

DISPOSAL

- Dispose of the packing materials (vinyl, styrofoam etc.) to keep them out of the reach of children.

 **Caution**

To reduce the risk of fire, electric shock, or personal injury when using the product, follow basic safety precautions, including the following:

INSTALLATION

- Do not tilt the product while moving or transporting it.
- This product is not designed for maritime use or for mobile installations such as RVs, trailers, or aircraft.
- Avoid installing product within 3 1/4 ft (1 m) of any TV or audio equipment.
- Do not place the product under bright light.
- The appliance shall be installed in accordance with national wiring regulations.
- When moving or storing the product, wrap the power cord around the base of the product to prevent personal injury, damage to the cord or damage to floors.
- Dropping the product may cause personal injury or product malfunction.

USAGE

- Do not use the product for removal of toxic gas such as carbon monoxide.
- Do not use the product for ventilation purposes.
- Do not connect the product to a power supply with unstable voltage for extended periods.
- Do not place obstacles around the air inlet or outlet.
- For safe use of the product, children or others with reduced mental capabilities need to be closely monitored by a person who is responsible for their safety.

- Do not place the product near curtains.
- Use this product only for its intended purpose. This product is not intended for use in preserving animals/plants, precision equipment, artwork, etc.
- Do not climb or place objects on the product.
- Do not operate the product with wet hands.
- Do not let the moisture from a humidifier directly touch the product.
- Do not use the product while it is not in an upright position.
- Do not use the product near objects vulnerable to heat.
- Use the filter only for its intended purpose.
- Do not use detergents, cosmetics, chemicals, air fresheners, or disinfectants in the product.
- Do not place magnetic or metal objects on top of the product.
- Clean with a soft cloth only. Do not use strong detergents or solvents to clean the product.
- Use the Booster mode only when necessary.
- Do not insert any objects into the Booster.
- Do not operate the product while the Booster cover and grille are separated.
- Do not insert hands or metal objects into the Booster.
- Do not modify the battery. Doing so may cause a fire or electric shock.
- Inserting the battery incorrectly may cause an explosion.
- Do not recharge or take apart the battery. Doing so may result in an explosion.
- Do not burn the battery or leave it near heat. Doing so may result in an explosion.