


Handheld Spray Fan ML-F006 User Manual



Type-C
Charging Port

Battery Indicator

Speed Button

Spray Button

-1-

Product Features:

- ① Adopting brushless motor, this handheld spray fan has strong airflow yet low noise and energy consumption. It has 3 speed options (low/medium/high). The fan has 3 high-end aerodynamic blades which make the airflow very strong. It also has spray function, making you even cooler in the hot summers.
- ② It is lightweight, portable and rechargeable, suitable for camping, treadmill, desktop, home, etc.
- ③ Built-in high energy density battery with capacity of 3000mAh. The maximum working time of the fan is about 3 hours at speed 3.
- ④ It is equipped with type-C charging port. When the device is out of power, you could also connect it with adapter (NOT included) for power supply. You can use the device during charging. The input current is 1A. It is compatible with computer or any ordinary USB port. Built-in charging protection integrated circuit, safe and reliable.
- ⑤ The grid of the fan is small enough to prevent fingers from passing through. It will auto stop when small sticks fall into the fan, totally safe!

Product Model	ML-F006
Input	5V/1A
Power	1-3W
Battery Capacity	3000mAh
USB Port	Type-C
Speed Setting	High / Medium / Low
Charging Time	About 4H
Battery Indicators	It will flash slowly in red during charging, and in steady blue when fully charged.
Battery Life	About 3-7H
Water Tank Capacity	50ml
Spray Ability	45ml/h
Spray Time	On setting 1, it sprays continuously; on setting 2, it sprays for 5s then stops for 5s and circulate this way.
Size	9.4*4.1*1.8 inch (239.5*105*45mm)
Weight	0.47 lb. (212.5g)

-2-

Packing List:

Spray Fan*1, Type-C Charging Cord*1, User Manual*1, 60ml Bottle*1

How to Use:

- ① Fan Control: short press the FAN button to switch among speed 1/2/3/OFF. Long press the button to turn off the fan at any speed.
- ② Spray Control: short press the MIST button to turn on/off the spraying function.

- ③ Please use 5V/1A adapter for charging.

Charging & Display:

- ① Fan is on: flash in green slowly.
- ② Spray is on: flash in blue slowly.
- ③ Fan and spray are on simultaneously: slowly flash in green and blue alternately.
- ④ Low voltage: slowly flash in red.
- ⑤ Different display when charging:
 - A. Flash in red during charging; show steady blue when fully charged.
 - B. Charging while the fan is on and the spray is off: steady red, flash in green.
 - C. Charging while the fan is off and the spray is on: steady red, flash in blue.
 - D. Charging while the fan and spray are on simultaneously: flash in red, green, blue alternately.

-3-

- ⑥ The fan can only run on the lowest setting during charging.

Attentions:

- ① Please do not squeeze or detach the battery or place the fan in high temperature (60℃ or above) for a long time, otherwise it may be at the risk of leakage or explosion.
- ② When the fan is working, please do not put your fingers or any foreign objects into the fan for the sake of your safety.
- ③ Please do not clean the fan with hard metal or corrosive liquid. Please do not disassemble the device.
- ④ Please store the fan out of the reach of children. The fan should be used by children under the supervision of adults.
- ⑤ When the fan is not used for a long time, it should be charged every 2-3 months and stored in a cool and dry place.
- ⑥ Please do not use the fan in humid environment.

-4-