


MM00147 INSTRUCTION MANUAL

ASSEMBLY • OPERATION • MAINTENANCE • SAFETY

(Nhot's in the Box:

Lay out all box components included on a level and comfortable workspace:





(1)



(L)

- (1)—A Circular Base
- (1)—B Vertical Height Pole
- (1)—C Curved Top Pole with Cap
- (1)—D Hanging Pin 15mm x 80mm
- (2)—E Round Hex Nut & Bolt M8 x 42mm
- (4)—F Lock Washers M8
- (1)—H Spring
- (1)—I Pod
- (1)—J Cushion
- (1)—K Bungee Cord w/ 2 Carabiners
- (2)—L Hex Wrench M8

M&M SALES ENTERPRISES, INC.

1300 Synergy Court, Dubuque, IA 52002 877-242-0514 www.mandmsalesinc.com

Swoon Pod

ASSEMBLY INSTRUCTIONS

ASSEMBLY WARNINGS:

- Due to the presence of small parts during assembly, keep components out of reach of children until assembly is complete.
- To prevent serious injury, children must not use Swoon Pod until properly assembled and installed.

BEFORE YOU BEGIN ASSEMBLY:

- Assembly should be completed by adult person.
- Place the equipment on level ground.
- Do not install Swoon Pod concrete, asphalt or any hard surface.
- A fall onto a hard surface can result in serious injury or death to the equipment user.
- No need to show gorilla strength while tightening bolts. Over-tightening bolts or nuts can cause the threads to get damaged making it difficult to take your Cozy Hanging Pod apart or reassemble it in the future.







(Steps 1-5) Build Stand:

- Place A (Circular Base) on a level surface with the non-skid feet resting on the floor surface.
- Connect B (Vertical Height Pole) to A (Circular Base) using one E (Round Hex Nut & Bolt) and two F (Washers). Tighten hardware.
- Insert C (Curved Top Section) of stand to B (Vertical Height Pole) using the remaining E (Round Hex Nut & Bolt) and two F (Washers). Tighten hardware.
- 4. Drop D (Hanging Pin) through the end of C (Curved Top Section). The cap of the pin should be on top.
- Insert one end of **H** (Spring) through the hole punched in the lower end of D (Hanging Pin).

(Steps 6-7) Connect Stand and Swoon Pod:

- Slide the circular hanger at the top of the pod frame to the open end of the H (Spring). Make sure Pod opening for entering/ exiting seating is facing outward away from the stand.
- Place J (Cushion) in Cozy Hanging Pod.

(Steps 8-9) Attach Motion Resistant Bungee Strap:

- Connect one Carabiner on K (Bungee Cord) to the horizontal rib running around the frame of the Pod.
- Bring K (Bungee Cord) around B (Vertical Height Pole) and return the other end to the same horizontal rib of Pod to secure other Carabiner. Confirm both Carabiners on K (Bungee Cord) are closed.









MM00147 INSTRUCTION MANUAL

ASSEMBLY • INSTALLATION • OPERATION • MAINTENANCE • SAFETY

OPERATION INSTRUCTIONS

OPERATION WARNINGS:

- Only for family residential domestic use.
- Designed for single person use. Children should use safely with on-site supervision.
- Maximum fall height 4 ft. (determined by product's tallest height)

BEFORE OPERATING INSTRUCT CHILDREN:

Do not walk close to, in front of, behind, or between moving users of equipment • Do not use equipment in a manner other than intended • Not to dismount equipment while they are in motion • Not to wear inappropriate items, such as but not limited to, loose fitting clothing, hood and neck drawstrings, scarves, cord-connected items, capes, and ponchos. These items can cause death by strangulation • Not to attach items to the equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause strangulation hazard • To remove bike or other sports helmet before playing on the equipment • Wear well-fitting and full foot enclosing footwear. Examples of inappropriate footwear are clogs, flip flops, and sandals • Jump in an area safe of obstructions on ground, air, or sky that you may encounter during jumping. Locate Cozy Hanging Pod on level, flat soft ground surface that has padding, or carpet under and surrounding it.

MAINTENANCE INSTRUCTIONS

BEGINNING OF EACH PLAY SEASON:

- Tighten all hardware.
- Check all protective coverings on bolts, pipes, edges, and corners. Replace if they are loose, cracked, or missing.
- Check all moving parts including poles, hardware, and tube for wear, rust, or other deterioration. Replace as needed.
- Check all metal parts for rust. If found, sand and repaint using a non-lead based paint meeting the requirements of 16 CFR 1303.

TWICE A MONTH:

- Tighten all hardware
- Check all protective coverings on bolts, pipes, edges, and corners and all moving parts including poles, hardware, and tube for wear, rust, or other deterioration. Replace as needed. Replace if they are loose, cracked, or broken.

DISPOSAL:

When you are ready to dispose of the product, make sure that all components are disposed of in accordance with local waste ordinances. Disassemble and dispose of the playground equipment in such a way that no unreasonable hazards will exist at the time the playground equipment is discarded.

WARNING:

- Owners shall be responsible for maintaining the legibility of the warning labels
- Failure to carry out these checks and inspections could result in fall, head injury, or death due to falls from equipment placed over hard surfaces or misuse of product.

SAFETY INFORMATION

To reduce the likelihood of injury please follow the guidelines as outlined in this instructions. You can visit our website www. mandmsalesinc.om to review the instruction manual in the future or keep this instruction sheet for reference:

The installation instructions above are reflective of the U.S. Consumer Product Safety Commission's Outdoor Playground Safety Handbook.

For a complete description of installation instructions and warnings for outdoor playground equipment you can visit our website at www.mandmsalesinc.com to link to the current CPSC handbookand review in its entirety

Our products are tested to ensure safety and compliance with Consumer Product Safety Improvement Act of 2008

(CPSIA) including specifications for lead paint and phthalates.



