- 1. Remove battery pack from tool and engage trigger safety lock-off 2.
- 2. Using the hex wrench **12** provided, loosen the two hex bolts **18** at the top of the magazine **7** and the hex bolt **19** on the foot of the tool.
- 3. Lift the magazine 7 away from the nailer.
- 4. Remove jammed/bent nail, using pliers if necessary. Clear out any debris in the nail channel if required.
- 5. Install the magazine back into position under the nose of the tool and tighten the two hex bolts 18 at the top of the magazine 7 and the hex bolt 19 on the foot of the tool.
- 6. Reinsert battery pack.
 - **NOTE:** The tool will disable itself and not reset until the battery pack has been removed and reinserted.
- 7. Reinsert nails into magazine (refer to Loading the Tool).
- 8. Release the pusher latch 8.
- 9. Disengage the trigger safety lock-off **2** when ready to continue nailing.
- If nails become jammed in the nosepiece frequently, have the tool serviced by an authorized DEWALT service center.

Repairs

The charger and batteries are not serviceable. There are no serviceable parts inside the charger or battery pack.



WARNING: To assure product SAFETY and RELIABILITY, repairs, maintenance and adjustment (including brush inspection and replacement, when applicable) should be performed by a factory service center or an authorized service center. Always use identical replacement parts.

Register Online

Thank you for your purchase. Register your product now for:

- WARRANTY SERVICE: Registering your product will help you obtain more efficient warranty service in case there is a problem with your product.
- CONFIRMATION OF OWNERSHIP: In case of an insurance loss, such as fire, flood or theft, your registration of ownership will serve as your proof of purchase.
- FOR YOUR SAFETY: Registering your product will allow us to contact you in the unlikely event a safety notification is required under the Federal Consumer Safety Act.

Register online at www.dewalt.com/account-login.

Three-Year Limited Warranty

For warranty terms, go to **www.dewalt.com/support/warranty**.

To request a written copy of the warranty terms, contact: Customer Service at DEWALT Industrial Tool Co., 701 East Joppa Road, Towson, MD 21286 or call **1-800-4-DEWALT** (**1-800-433-9258**).

LATIN AMERICA: This warranty does not apply to products sold in Latin America. For products sold in Latin America, see country-specific warranty information contained in

the packaging, call the local company or see website for warranty information.

FREE WARNING LABEL REPLACEMENT: If your warning labels become illegible or are missing, call **1-800-4-DEWALT** (**1-800-433-9258**) for a free replacement.