



CAULK CORD WEATHERSEAL

Easy to Use:

- No caulk gun required
 - Seal window panes
 - Seals cracks & prevents drafts
 - Plug holes
1. Make sure surface is clean and free of dirt, moisture, grease and old caulk.
 2. Carefully peel top layer of cord “beads”. Separate individual beads according to desired width of gap.
 3. Press cord into opening and form to desired shape. For large gaps, use several cord beads.
 4. Place unused cord back in carton for future use.