

# **USE AND CARE GUIDE**

### **Cooper Springs White Square Metal Slatted Top Outdoor Dining Table**



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

#### THANK YOU

## **Table of Contents**

Table of Contents	2
Important Safety Instructions	2
Warranty	3
5 Year Frame Limited Warranty	3
What Is Covered	3
What Is Not Covered	3
Care & Cleaning	3

Pre-Assembly	 4
Planning Assembly	 4
Hardware Included	 5
Package Contents	 6
Completing Assembly	 8

## **Important Safety Instructions**

#### **Save these instructions**

#### **READ ALL INSTRUCTIONS BEFORE USE**

When using furnishing, basic precautions should always be followed, including the following: Read all instructions before using this furnishing.

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- 2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

## Warranty

#### **5 YEAR FRAME LIMITED WARRANTY**

#### WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for 5 years.

#### WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

## **Care & Cleaning**

Before using, wipe with a clean, dry cloth. Do not use bleach or solvents. Treat frame with one step liquid wax for maximum protection against UV light and salty, damp air. When not in use, store furniture in a cool, dry place. If your set includes cushions, they may be cleaned by hand with a mild solution of soap and water. Rinse cushion thoroughly and allow to drip dry. Do not machine wash or tumble dry, as cushions may shrink. Do not use bleach or solvents on fabrics. When cleaning the tabletop make sure to use a soft, clean cloth that doesn't bleed color as well.

Contact the Customer Service Team at 1-800-986-3460 or visit www.HomeDepot.com/HomeDecorators.

## **Pre-installation**

#### **PLANNING INSTALLATION**

It will take one person about 15 minutes to complete the assembly process.

#### **HARDWARE INCLUDED**




### **Dining Table**



Part	Description	Quantity
AA	BOLT CAP (M6)	16
BB	BOLT (M6*15)	16
CC	WASHER1 (φ6*12)	16
DD	ALLEN KEY	1

# **Pre-installation (continued)**

## **PACKAGE CONTENTS**




	Part	Description	Quantity
4	Α	TABLETOP	1
16	В	LEG	4
4	С	LID	1

4 - Hardware Packs

# **Installation – [Dining Table]**

# **1** Attaching legs


- □ Place the table top (A) upside down on a flat, smooth surface.
- $\Box$  Align the table legs (B) to the table top (A).
- □ Secure the table legs (B) to the table top (A) with washers (CC) and bolts (BB) using the hex wrench.
- □ Fully tighten all bolts (BB) once all bolts are in place. Cover all bolts (BB) with bolt caps (AA).



# Installation – [Dining Table]

# **2** Attaching lid

 $\hfill\Box$  Cover the table top (A) with the lid (C).



# **Completing Assembly**





Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

### HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.

For certification use only

Factory Dinging Table ID:S21-44SCS-DT