

## **Stainless Steel Sink Care:**

After Each Use:

- Remove all objects from sink.
- Clean with light soap solution, rinse and drain all water and towel dry.

## **Regular Maintenance:**

Side Walls and Bottom of Sink: Remove stains using a cleaning product that contains mild abrasives; always wipe in grain finish. Pay careful attention to the directional change.

## **Mineral Deposits:**

Use a cleaning product that contains mild abrasives or a light solution of vinegar and water(1:20 ratio); rinse well and towel dry.

**CAUTION:** Stainless steel requires exposure to air; DO NOT leave items, objects, cloths, mats, water, pots, pans, cast irons, knives, etc., in the sink when not washing.

## **DO NOT:**

- Use steel wool or other metal or coarse scouring pads.
- Stand on or in sink when cleaning windows, reaching for top shelf, painting, etc.
- Drop heavy objects in sink as this will cause denting.
- Leave water, bleach, other cleaners or chemicals of any type in sink; always rinse sink after any use and dry with towel.
- Use concentrated bleach, always dilute with water and rinse thoroughly after use.
- Use any acids, drain cleaners, harsh chemicals, paint removers, metal cleaners, etc., in sink.
- Drop sharp objects in sink or use as a cutting surface.

**Have a question? DON'T GO BACK TO THE STORE, WE CAN HELP, just call 1-800-626-3525, 8 a.m. to 5 p.m. EST Monday-Friday, or send an email to [Help@cmiproduct.com](mailto:Help@cmiproduct.com).**