

Cleaning & Maintenance

Warning: Do not use any alcohol or fume for cleaning/sanitization of the ice machine. It may cause cracks on the plastic parts. Ask a trained service person to check and clean the condenser at least once a year, in order to let the unit work properly. This appliance must be cleaned by use water jet.

CAUTION: If the ice machine has been left unused for a long time, before the next use it must be thoroughly cleaned. Follow carefully any instructions provided for cleaning or use of sanitizing solution.

- Do not leave any solution inside the ice machine after cleaning.
- Periodic cleaning and proper maintenance will ensure efficiency, top performance, hygienic, and long life. The maintenance intervals listed are based on normal conditions. You may want to shorten the intervals if you have pets, or there are other special considerations.

What Shouldn't Be Done

Never keep anything in the ice storage bin that is not ice: objects like wine and beer bottles are not only unsanitary but also their labels may slip off and obstruct the drain pipe.

Exterior Cleaning

The door may be cleaned with a mild detergent and warm water. Do not use solvent-based or abrasive cleaners. Use a soft sponge and rinse with clean water. Wipe dry with a soft clean towel to prevent water spotting.

NOTE: Stainless steel models exposed to chlorine gas and moisture, such as in areas with spas or swimming pools, may have some discoloration of stainless steel. Discoloration from chlorine gas is normal.

Interior Cleaning

For Ice Storage Bin

The ice storage bin should be sanitized occasionally. Clean the bin before the ice machine is used for the first time and reused after stopping for an extended period of time. It is usually convenient to sanitize the bin after the outside, the storage bin must be empty.

1. Disconnect power to the unit.
2. Open the door and with a clean cloth, wipe down the interior with a sanitizing

solution made of 28g of household bleach or chlorine and 7.5L of hot water.

3. Rinse thoroughly with clear water. The waste water will be drained out through the drain pipe.
4. Reconnect power to the unit.
5. The ice scoop should be washed regularly. Wash it just like any other food container.

WARNING: Do not use solvent-based or abrasive cleaners. These may transmit taste to the ice cubes.

Cleaning Suggestion

1. DAILY CLEANING

The ice spoon, door and the water dividing pipe should be cleaned by yourself per each day. At the end of every day, rinse the ice spoon and wipe the both sides of the door with a clean cloth.

2. SEMI-MONTHLY CLEANING

The ice bin, water tank, the ice-full detecting plate and the surface of the evaporator are to be cleaned by yourself semi-monthly according to interior cleaning program.

3. QUARTERLY CLEANING

All the components and surfaces exposed to water or ice cubes, like ice storage bin, water tank, door, evaporator, water pump, water dividing pipe, etc. should be cleaned 3 months according to the following steps:

- a. Disassemble the front panel
- b. Add water and vinegar or lemon juice mix (1:1 ratio) or other similar acid detergent into the water tank.
- c. Press “Clean” icon to make the machine enter self-clean mode, this process takes about 10 minutes. When the Self-clean program is finished, drain off any remaining water.

NOTE: It is strongly recommended to clean the unit before initial use or after the unit has not been in use for a long period of time.