


Item #1006 452 258  
1006 452 256  
Model # FRS81312A-BLK  
FRS81312A-BLD

# HAMPTON BAY

## USE AND CARE GUIDE

---

### RICHMONT STEEL WICKER EGG CHAIR



Questions, problems, missing parts? Before returning to the store,  
call Hampton Bay Customer Service  
8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

**1-855-HD-HAMPTON**

**HOMEDEPOT.COM**

---

#### **THANK YOU**

*We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!*

# Table of Contents

Table of Contents.....	2	Pre-Assembly .....	3
Important Safety Instructions .....	2	Planning Assembly .....	3
Save These Instructions .....	2	Hardware Included .....	3
Read All Instructions Before Use .....	2	Chair Package Contents .....	4
Warranty .....	3	Chair Assembly .....	5
What is Covered .....	3	Care and Cleaning .....	8
What is Not Covered .....	3		

## Important Safety Instructions

### SAVE THESE INSTRUCTIONS



**WARNING:** This chair was made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this set when any formidable / severe weather is approaching.



**WARNING:** Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

### READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Do not move the chair while the chair is occupied. Failure to obey this could result in injury.
4. Do not rock in the chair as you may fall and incur serious injury.
5. Please keep children out of the assembly area before assembly.



**WARNING:** This chair is heavy, and may require two adults for safe assembly.



**WARNING:** Do not place heavy objects on the chair.



**WARNING:** Weight limit for the chair is 250 lbs. (113.39 kg).



**CAUTION:** When not in use, secure the product in a cool and covered location.



**CAUTION:** Do not locate the product near any heat source.

# Warranty

## 3-YEAR FRAME AND 3-YEAR FABRIC LIMITED WARRANTY

### WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three (3) years, and a three (3) year limited warranty for the fabric.

### WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit [www.HOMEDEPOT.COM](http://www.HOMEDEPOT.COM).

# Pre-Assembly

## PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



**NOTE:** More than one person may be required to assemble this product.

## HARDWARE INCLUDED



**NOTE:** Hardware not shown to actual size.



AA



BB



CC



DD




EE

Part	Description	Quantity
AA	M6x50 Combination Bolt	16+1
BB	M6 Washer	8+1
CC	M6 Nut	8+1
DD	Hex Wrench	1
EE	Wrench	1

# Pre-Assembly (continued)

## CHAIR PACKAGE CONTENTS




Part	Description	Quantity
A	Chair Back	1
B	Chair Seat	1
C	Right Arm	1
D	Left Arm	1
E	Right Panel	1
F	Left Panel	1
G	Top Panel	1
H	Back Cushion	1
I	Seat Cushion	1
J	Bolster	2
K	Lumbar Cushion	1

# Chair Assembly


## 1 Attaching the Left Arm to the Chair Back

- Place the chair back (A) on a soft surface.
- Attach the left arm (D) to the chair back (A) using M6x50 combination bolts (AA).
- Do not tighten all bolts at this step.



## 2 Attaching the Right Arm to the Chair Back


- Attach the right arm (C) to the chair back (A) using M6x50 combination bolts (AA).
- Do not tighten all bolts at this step.



## Chair Assembly (continued)


### 3 Attaching the Chair Seat to the Left Arm and Right Arm

- Attach the chair seat (B) to the left arm (D) and right arm (C) using M6x50 combination bolts (AA).
- Do not tighten all bolts at this step.



### 4 Attaching the Right Panel to the Top Panel


- Attach the right panel (E) to the top panel (G) using an M6x50 combination bolt (AA), M6 washer (BB) and M6 nut (CC).
- Do not tighten all bolts at this step.



## Chair Assembly (continued)


### 5 Attaching the Left Panel to the Top Panel

- Attach the left panel (F) to the top panel (G) using an M6x50 combination bolt (AA), M6 washer (BB) and M6 nut (CC).
- Do not tighten all bolts at this step.



### 6 Attaching the Left Panel to the Left Arm, Right Panel to the Right Arm


- Attach the left panel (F) to the left arm (D), right panel (E) to the right arm (C) using M6x50 combination bolts (AA), M6 washer (BB) and M6 nut (CC).
- Do not tighten all bolts at this step.



## Chair Assembly (continued)

### 7 Tightening All Bolts and Put the Cushions

- Turn the chair right up.
- Once all of the bolts are in place, fully tighten all the bolts using hex wrench (DD) and wrench (EE).
- Put the seat cushion (I) back cushion (H), bolsters (J) and lumbar cushion (K) on the chair.



## Care and Cleaning

- For best results, clean the set with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach, or solvents.
- Store the set in a dry, sheltered place when not in use.
- Keep the set away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

# HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,  
call Hampton Bay Customer Service.  
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

**1-855-HD-HAMPTON**

**HOMEDEPOT.COM**

Retain this manual for future use.

For certification use only
Factory ID # FRS81312A